



1986

BMW 528e/535i

Electrical

Troubleshooting

Manual

BMW of North America, Inc.
Montvale, New Jersey

FOREWORD

In the interests of continuing technical development work we reserve the right to modify designs and equipment.

Printed in USA

©Copyright BMW of North America, Inc.

Not to be reproduced wholly or in part
without written permission of BMW of
North America, Inc.

PN 89 89 1 000 173

**1986
BMW 528e/535i
Electrical
Troubleshooting
Manual**

CONTENTS

How To Use This Manual	3
Symbols	4
Wire Size Conversion Chart	5
Systematic Troubleshooting	6
Section A: 528e Schematic Diagrams	
528e Index	2
Diagnostic Connector	8500-0
Power Distribution Box	0670-0
Fuse Data	0670-1
Component Location Chart	9000-0
Component Location Views	7000-0
Splice Location Views	8000-0
Section B: 535i Schematic Diagrams	
535i Index	2
Diagnostic Connector	8000-0
Power Distribution Box	0670-0
Fuse Data	0670-1
Component Location Chart	9000-0
Component Location Views	7000-0
Splice Location Views	8000-0

The purpose of this manual is to show electrical schematics in a manner that makes electrical troubleshooting easier. Electrical components which work together are shown together on one schematic. The Wiper-Washer schematic, for example, shows all of the electrical components in one diagram. At the top of the page is the fuse (positive) that powers the circuit. The flow of current is shown through all wires, connectors, switches, and motors to ground (negative) at the bottom of the page.

Within the schematic, all switches and sensors are shown "at rest," as though the Ignition Switch were off. For identification, component names are underlined and placed next to or above each component. Notes are included, describing how switches and other components work.


The power distribution schematic shows the current feed through all the connections from the Battery and Alternator to each fuse and the Ignition and Light Switches. If the Power Distribution schematic is combined with any other circuit schematic, a complete picture is made of how that circuit works. The Ground Distribution schematics show how several circuits are connected to common grounds.

All wiring between components is shown exactly as it exists in the vehicle; however, the wiring is not drawn to scale. To aid in understanding electrical operation, wiring inside complicated components has been simplified. The "Solid State" label designates electronic components.


WIRE SIZE CONVERSION CHART	
METRIC (CROSSSECTIONAL AREA IN MM ²)	AWG (AMERICAN WIRE GAUGE)
.5	20
.75	18
1	16
1.5	14
2	14
2.5	12
4	10
6	8
8	8
16	4
20	4
25	2
32	2

WIRE INSULATION	
ABBREVIATIONS	COLOR
BK	BLACK
BR	BROWN
RD	RED
YL	YELLOW
GN	GREEN
BU	BLUE
VI	VIOLET
GY	GRAY
WT	WHITE
PK	PINK



4 SYMBOLS




ENTIRE COMPONENT SHOWN




COMPONENT CASE IS DIRECTLY ATTACHED TO METAL PART OF CAR (GROUNDED)




PART OF A COMPONENT SHOWN




INDICATES THAT FUSE 5 IS ALWAYS SUPPLIED WITH POWER









COMPONENT WITH SCREW TERMINALS




INDICATES THAT FUSE 6 IS SUPPLIED WITH POWER WITH THE IGNITION SWITCH IN THE RUN OR START POSITIONS




SOLID STATE (INCLUDES ONLY ELECTRONIC PARTS)







ONE POLE,
TWO POSITION
SWITCH



SWITCHES THAT
MOVE TOGETHER
DASHED LINE SHOWS
A MECHANICAL
CONNECTION
BETWEEN SWITCHES




TWO CONNECTIONS
(PINS) IN THE SAME
CONNECTOR
DASHED LINE SHOWS
PARTS OF THE
SAME CONNECTOR





WHEN COIL IS
ENERGIZED, SWITCH
IS PULLED CLOSED

RELAY SHOWN
WITH NO
CURRENT
FLOWING
THROUGH
COIL






RESISTOR ACROSS COIL
IS FOR NOISE
SUPPRESSION

RELAY SHOWN
WITH RESISTOR
ACROSS COIL



CURRENT PATH
IS CONTINUED
AS LABELED.
THE ARROW SHOWS
DIRECTION OF CURRENT
FLOW AND IS REPEATED
WHERE CURRENT
PATH CONTINUES.



LIGHT
EMITTING
DIODE

6 SYSTEMATIC TROUBLESHOOTING

TROUBLESHOOTING PROCEDURE

1. Verify the Problem

Operate the problem circuit to check the accuracy of the complaint. Note the symptoms of the inoperative circuit.

2. Analyze the Problem

Refer to the schematic of the problem circuit in the ETM. Determine how the circuit is supposed to work by tracing the current path(s) from the power feed through the circuit components to ground. Then based on the symptoms you noted in step 1 and your understanding of circuit operation, identify one or more possible causes of the problem.

3. Isolate the Problem

Make circuit tests to prove or disprove the preliminary diagnosis made in step 2. Keep in mind that a logical simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points which are easily accessible.

4. Repair the Problem

Once the specific problem is identified, make the repair using the proper tools and safe procedures.

5. Check the Problem

Operate the circuit to check for satisfactory circuit operation. Good repair practice calls for rechecking all circuits you have worked on.

TROUBLESHOOTING TOOLS


Isolating the problem (Step 3 of TROUBLESHOOTING PROCEDURES) requires the use of a **voltmeter** and/or **ohmmeter**. A voltmeter measures voltage at selected points in a circuit. An ohmmeter measures a circuit's resistance to current flow. It has an internal battery that provides current to the circuit under test. Disconnect the car battery when using an ohmmeter because the battery voltage will cause the ohmmeter to give false readings. Also, do not use an ohmmeter on solid-state components. The voltage that the ohmmeter applies to the circuit could damage these components.

TROUBLESHOOTING TESTS

Voltage Test

This test measures voltage in a circuit. By taking measurements at several points (terminals or connectors) along the circuit, you can isolate the problem.

To take a voltage measurement, connect the negative lead of the voltmeter to the battery's negative terminal or other known good ground. Then connect the positive lead of the voltmeter to the point you want to test. The voltmeter will measure the voltage present at that point in the circuit.




Voltage Test

Voltage Drop Test

Wires, connectors, and switches are designed to conduct current with a minimum loss of voltage. A voltage drop of more than one volt indicates a problem.


To test for voltage drop, connect the voltmeter leads to connectors at either end of the circuit's suspected problem area. The positive lead should be connected to the connector closest to the power source. The voltmeter will show the voltage drop between these two points.



Voltage Drop Test

Continuity Test

To perform a continuity test, first disconnect the car battery. Then adjust the ohmmeter to read zero while holding the leads together. Connect the ohmmeter leads to connector or terminals at either end of the circuit's suspected problem area. The ohmmeter will show the resistance across that part of the circuit.




Continuity Test

Short Test Using Voltmeter

Remove the blown fuse and disconnect the load. Connect the voltmeter leads to the fuse terminals. The positive lead should be connected to the terminal closest to the power source.

Starting near the POWER DISTRIBUTION BOX, move the wire harness back and forth and watch the voltmeter reading. If the voltmeter registers a reading, there is a short to ground in the wiring. Somewhere in the area of the harness being moved, the wire insulation is worn away and the circuit is grounding.




Short Test Using Voltmeter

8 SYSTEMATIC TROUBLESHOOTING

Short Test Using Ohmmeter

Disconnect the battery. Adjust the ohmmeter to read zero while holding the leads together. Remove the blown fuse and disconnect the load. Connect one lead of the ohmmeter to the fuse terminal that is closest to the load. Connect the other lead to a known good ground.

Starting near the POWER DISTRIBUTION BOX, move the wire harness back and forth and watch the ohmmeter reading. Low or no resistance indicates a short to ground in the wiring. Infinitely high resistance indicates no short.



Short Test Using Ohmmeter

SECTION A: 528e

1986 BMW 528e Electrical Troubleshooting Manual

CONTENTS

How To Use This Manual	3
Symbols	4
Wire Size Conversion Chart	5
Systematic Troubleshooting	6
Section A: 528e Schematic Diagrams	
528e Index	2
Diagnostic Connector	8500-0
Power Distribution Box	0670-0
Fuse Data	0670-1
Component Location Chart	9000-0
Component Location Views	7000-0
Splice Location Views	8000-0

Alphabetical Listing of Electrical Circuits

	PAGE		PAGE		PAGE
Active Check Control	6216-0	Heating		— Front Park	6314-0
Air Conditioning		— Blower	6413-0	— Glove Box	6100-2
— Blower	6413-0	— Temperature Controls	6411-0	— Hazard Warning	6313-0
— Temperature Control	6411-0	Horn	6100-0	— Headlights	6312-1
AntiLock Brake	3450-0	Idle Speed Control	1360-0	— High Level Stop Light	6325-0
Auto-Charging Flashlight	6100-2	Ignition	1360-1	— Interior	6330-0
Auxiliary Fan	6454-0	Ignition Key Warning	6131-0	— License	6320-0
Brake Lining Warning	3435-0	Indicators		— Rear Defogger Switch	6300-3
Central Locking	5126-0	— “Brake Lights” Fault	6216-1	— Rear Marker	6320-0
Charging System	1230-0	— “Brake Lining Wear”	3435-0	— Stoplight	6325-0
Cigar Lighter	6100-2	— “Brake” Warning	6210-2	— Tail	6314-0
Component Location Views	7000-0	— Charge	6210-0	— Transmission Range	6300-2
Connectors		— “Coolant Level” Fault	6216-2	— Turn	6313-1
— Accessory	8500-1	— “Engine Oil” Fault	6216-2	— Trunk	6320-0
— Diagnostic	8500-0	— Fasten Seatbelts	6216-2	Light Switch Details	6300-0
Connector Views	8500-2	— Foglights	6210-2	On-Board Computer	6581-0
Cruise Control	6571-0	— High Beam	6210-2	Power Antenna	6500-0
Engine Control Block Diagram	1250-0	— Inspection	6210-3	Power Distribution	0670-2
Fuel Control	1360-3	— LH Turn	6210-2	Power Distribution Box	0670-0
Fuel Delivery	1360-2	— “License Plate” Fault	6320-0	Power Mirrors	5116-0
Fuse Data	0670-1	— “Low Beam” Fault	6216-0	Power Seats	5200-0
Fuse Details		— Low Fuel Warning	6210-1	Power Windows	5133-0
— Fuse 4	0670-5	— “O ₂ Sensor”	6210-0	Radio	6500-0
— Fuse 5	0670-8	— Oil Pressure Warning	6210-1	Rear Defogger	6100-1
— Fuse 6	0670-4	— Oil Service	6210-3	Seatbelt Warning	6131-0
— Fuse 11	0670-6	— “Park Brake”	6210-1	Service Interval Indicator	6210-3
— Fuse 12	0670-7	— “Rear Lights” Fault	6216-1	Speedometer	6210-0
— Fuse 13	0670-5	— RH Turn	6210-2	Splice Location Views	8000-0
— Fuse 14	0670-7	— “Washer Fluid” Fault	6216-2	Start	
— Fuse 17	0670-5	Lights		— Automatic	1240-0
Gauges	6210-0	— A/C Panel	6300-3	— Manual	1240-1
— Fuel	6210-1	— Ashtray	6300-3	Sunroof	5413-0
— Tach/Fuel Economy	6210-0	— Backup	6322-0	Tachometer	6210-0
— Temperature	6210-1	— Brake	6325-0	Warnings	
Ground Distribution	0670-9	— Dash	6300-2	— Ignition Key	6131-0
Heated Door Locks	6100-1	— Dome	6330-0	— Seatbelt	6131-0
		— Fog	6312-0	Washer Jet Heaters	6160-0
		— Front Marker	6314-0	Wiper/Washer	6160-0

POWER DISTRIBUTION BOX

NOTE
 On some cars, the position of the side mounted relays may be interchanged on their respective sides. Check relay wire colors for positive identification.






Figure 1- Top Of Left Front Wheel Well


Fuse No.	Size/Color	Circuit Name
1	16A (RD)	Fuel Delivery
2	8A (WT)	Active Check Control (also fuses 3, 5, 6, 9, 10, 11, 12); Headlights (RH Low Beam).
3	8A (WT)	Active Check Control (also fuses 2, 5, 6, 9, 10, 11, 12); Headlights (LH Low Beam).
4	25 (BU)	Cigar Lighter; Radio/Power Antenna (also 5, 12); Power Seats.
5	8A (WT)	Active Check Control (also fuses 2, 3, 6, 9, 10, 11, 12); Heated Door Locks; Ignition Key Warning/Seatbelt Warning (also fuse 6); Interior Lights (also fuse 6); Lights: Turn/Hazard Warning (also fuse 11); Lights: Trunk; Glove Box/Auto-Charging Flashlight; Central Locking; On-Board Computer (also fuses 6, 12); Radio/Power Antenna (also fuses 4, 12); Service Interval Indicator (also fuse 6).
6	8A (WT)	Active Check Control (also fuses 2, 3, 5, 9, 10, 11, 12); Back Up Lights/Transmission Range Lights; Cruise Control (also fuse 12); Dash Lights (also fuses 9, 14); Fog Lights (also fuses 15, 16); Gauges; Heater/Air Conditioning (also fuse 14); Idle Speed Control; Ignition; Interior Lights (also fuse 5); On-Board Computer (also fuses 5, 12); Power Mirrors; Power Windows (also Power Window Circuit Breaker); Seatbelt Warning (also fuse 5); Service Interval Indicator (also fuse 5); Speedometer; Warning Indicators;
7	8A (WT)	Headlights (RH High Beams).

Fuse No.	Size/Color	Circuit Name
8	8A (WT)	Headlights (LH High Beams);
9	8A (WT)	Active Check Control (also fuses 2, 3, 5, 6, 10, 11, 12); Dash Lights (also fuses 6, 14); Lights: Front Park/Front Marker/Tail: (also fuse 10); Lights: Rear Marker/License: (also fuse 10).
10	8A (WT)	Active Check Control (also fuses 2, 3, 5, 6, 9, 11, 12); Lights: Front Park/Front Marker/Tail; Lights: Rear Marker/License (also fuse 9).
11	16A (RD)	Active Check Control (also fuses 2, 3, 5, 6, 9, 11, 12); Lights: Turn/Hazard Warning (also fuse 5); Wiper/Washer and Heater Washer Jets; Horn.
12	8A (WT)	Active Check Control (also fuses 2, 3, 5, 6, 9, 10, 11); Cruise Control (also fuse 6); Radio (also fuse 4, 5); Stop Lights; On-Broad Computer (also fuses 5, 6); Power Antenna (also fuses 4, 5).
13	16A (RD)	Rear Defogger; Sunroof.
14	25A (BU)	Auxiliary Fan (also fuse 17); Dash Lights (also fuses 6, 9); Heater/Air Conditioning (also fuse 6).
15	8A (WT)	Fog Lights (RH).
16	8A (WT)	Fog Lights (LH).
17	25A (BU)	Auxiliary Fan (also fuse 14).
Power Window Circuit Breaker	25A (BU)	Power Windows (also fuse 6).






FUSE DETAILS: FUSES 4, 17 and 13




FUSE DETAILS: FUSE 11




FUSE DETAILS: FUSES 12 AND 14


HOT IN RUN ONLY FROM UNLOADER RELAY





HOT IN ACCY, RUN OR START




FUSE DETAILS: FUSE 5







0670-10 POWER DISTRIBUTION



GROUND DISTRIBUTION (G200)




GROUND DISTRIBUTION (G200, G201)




GROUND DISTRIBUTION (G102 AND G301)




AUTOMATIC ONLY




MANUAL ONLY







IDLE SPEED CONTROL





FUEL DELIVERY




FUEL CONTROL













HOT IN RUN OR START



1. MOTOR DIRECTION CONTROLLED BY POLARITY
2. WITH CLUTCH SOLENOID ENERGIZED MOTOR TURNS MIRROR LEFT OR RIGHT
3. ELECTRICALLY HEATED MIRROR TURNS ON BELOW $59 \pm 9^\circ \text{ F}$ AND TURNS OFF ABOVE $122 \pm 18^\circ \text{ F}$







TROUBLESHOOTING HINT

Check Fuse 5 by operating the Digital Radio.

SYSTEM CHECK

- Operate controls in sequence listed in the System Check Table.
- Refer to Repair Action for the Response received (Tests follow the System Check Table).
- After any repair, repeat System Check to verify proper system operation.

NOTE: Before replacing any system component, check all connectors, splices, and wiring to that component.

COMPONENT LOCATION

	Page-Figure
Central Locking Control Unit	Behind RH kick panel, above speaker 7000-10-4
Door Lock Motors	Center Rea of respective door 7000-10-4
Gas Filler Lock Motor	In trunk, right of power antenna 7000-12-4
Ignition Switch	Upper part of steering column
Power Distribution Box	On LH front wheel well 7000- 3-2
Right Front Door Micro Switch	Inside RH front door, mounted on door lock. 7000-10-4
Trunk Lock Motor	In rear panel of trunk. 7000-12-3
Unlock Inhibit Switch	In LH front door, on door lock. 7000- 9-4
C200 (10 pin)	On LH side of steering column 7000- 7-6
C206 (29 pin)	On connector bracket, under LH side of dash 7000- 7-4
C302 (Accessory Connector)	Under LH side of dash. 7000- 7-4
C400 (13 pin)	Behind LH front speaker 7000- 9-2
C401 (13 pin)	Behind RH front speaker. 7000-10-3
C402 (7 pin)	In LH B pillar
C403 (7 pin)	In RH B pillar 7000-5-6
C404 (5 pin)	In bottom rear of LH front door
C405 (2 pin)	In trunk, near trunk lock
C500 (6 pin)	Behind LH front speaker 7000- 9-2
G200 (Front Interior Ground)	Under LH side of dash, near brake bracket. . 7000- 7-6

SYSTEM CHECK TABLE

OPERATION	RESPONSE	REPAIR ACTION
1. Insert the key in the Driver's door and turn to LOCK	All doors lock	None, proceed to Operation 2
	Some doors lock	Repair/replace the suspect Door Lock Motor circuit
	No doors lock	Proceed to Operation 4
2. Turn the key to UNLOCK INHIBIT (clockwise until key is horizontal)	All doors double lock (Safety Catch Buttons cannot be pulled up by hand)	None, proceed to Operation 3
	Driver's door double locks and only some of the other doors double lock	Repair/replace the suspect Door Lock Motor
	Driver's door double locks but all the other doors do not double lock	Turn key to UNLOCK. If any door unlocks, check RD/BR wire and Unlock Inhibit Switch. If no doors unlock, proceed to Test B.
	Driver's door does not double lock	Mechanical problem, see BMW Troubleshooting Manual

SYSTEM CHECK TABLE (CONT'D)

OPERATION	RESPONSE	REPAIR ACTION
3. Turn the key to UNLOCK	All doors unlock	None, proceed to Operation 4
	Some doors unlock	Repair/replace the suspect Door Lock Motor circuit
	No doors unlock	Proceed to Operation 5
4. Insert the key in the Passenger's door and turn to LOCK	All doors lock	If the doors did not lock in Operation 1, repair/replace the Driver's Door Lock Switch, otherwise proceed to Operation 5
	Some doors lock	Repair/replace the suspect Door Lock Motor circuit
	No doors lock	If all the doors locked in Operation 1, repair/replace the Right Front Door Microswitch. If the doors did not lock in Operation 1, perform Test A
5. Insert the key in the Passenger's door and turn to UNLOCK	All doors unlock	If all the doors did not unlock in Operation 3, repair/replace the Driver's Door Lock Switch, otherwise proceed to Operation 6
	Some doors unlock	Repair/replace the suspect Door Lock Motor
	No doors unlock	If all the doors unlocked in Operation 3, repair/replace the Passenger's Door Lock Switch. If the doors did not unlock in Operation 3, perform Test C
6. Get in the car and close and lock all doors Turn the Ignition Switch to RUN	Doors remain locked	None, proceed to Operation 7
	Doors unlock	Repair/replace the Central Locking Control Unit
7. Get out of the car Insert the key in the Driver's door and turn to LOCK Unlock each of the doors by pulling up the Safety Catch Buttons	All doors can be unlocked	None, proceed to Operation 8
	All doors remain secure	Disconnect the connector from the Central Locking Control Unit and check for a short to battery in the RD/BR, WT/BU, and BK/WT wires at terminal 10. <ul style="list-style-type: none"> • If short to battery is not present, replace the Unlock Inhibit Switch. • If short to battery is present, isolate wiring from Door Lock Motors one at a time to find short

SYSTEM CHECK TABLE (CONT'D)

OPERATION	RESPONSE	REPAIR ACTION
8. Insert the key in the Trunk Cylinder Switch. Turn the key to LOCK	Trunk locks	None, proceed to Operation 9
	Trunk does not lock	If the doors lock, repair/replace the Trunk Lock Motor Circuit or Trunk Lock Motor. If the doors do not lock, repair/replace the Trunk Switch. Repair/replace the Central Locking Control Unit if the Trunk Switch Circuit is OK
9. Turn the key to UNLOCK	Trunk unlocks	None, proceed to Operation 10
	Trunk does not unlock	If the doors unlock, repair/replace the Trunk Lock Motor circuit or Trunk Lock Motor. If the doors do not unlock, repair/replace the Trunk Switch. Repair/replace the Central Locking Control Unit if the Trunk Switch Circuit is OK
10. Turn the key back to LOCK	Gas Filler locks	None, proceed to Operation 11
	Gas Filler does not lock	Repair/replace the Gas Filler Lock Motor circuit
11. Turn the key to UNLOCK	Gas Filler unlocks	None
	Gas Filler does not unlock	Repair/replace the Gas Filler Lock Motor circuit

- If all results are normal, the system is OK.

SYSTEM DIAGNOSIS

- Do the following tests when directed by the System Check Table.

A: CONTROL UNIT LOCK TEST (TABLE 1)

Measure: VOLTAGE At: CONTROL UNIT CONNECTOR (Connected)		
Measure Between	Correct Voltage	For Diagnosis
3 (RD/WT) & Ground	Battery	See 1
3 (RD/WT) & 4 (BR)	Battery	See 2
<ul style="list-style-type: none"> • If the voltages are correct, proceed to Table 2. 1. Check the RD/WT wire for an open. 2. Check the BR wire for an open to ground (see schematic). 		

A: CONTROL UNIT LOCK TEST (TABLE 2)

Connect: A FUSED JUMPER At: CONTROL UNIT CONNECTOR (Connected)		
Jumper Between	Correct Result	For Diagnosis
7 (YL/BU) & Ground	Doors lock	See 1
<ul style="list-style-type: none"> • If the result is correct, repair/replace the switches and related wiring (see schematic). 1. Proceed to Table 3. 		

A: CONTROL UNIT LOCK TEST (TABLE 3)

Connect: A FUSED JUMPER At: CONTROL UNIT CONNECTOR (Disconnected)		
Jumper Between	Correct Result	For Diagnosis
1 (BU) & 3 (RD/WT) 2 (WT) & 4 (BR)	Doors lock	See 1
<ul style="list-style-type: none"> If the result is correct, replace the Central Locking Control Unit. <ol style="list-style-type: none"> Check the BU wire to splice S405 and the WT wire to splice S406 for opens (see schematic). 		

B: UNLOCK INHIBIT TEST (TABLE 1)

Measure: RESISTANCE At: CONTROL UNIT CONNECTOR (Disconnected)		
Conditions		
• Driver's Door Lock: UNLOCK INHIBIT		
Measure Between	Correct Resistance	For Diagnosis
10 (RD/BR) & Ground	1 K ohm	See 1
<ul style="list-style-type: none"> If the resistance is correct but the unlock inhibit only operates on the Driver's Lock, replace the Central Locking Central Unit. <ol style="list-style-type: none"> Check for opens in the WT/BK, BK/WT and BR wires. If OK, proceed to Table 2. 		

B: UNLOCK INHIBIT TEST (Table 2)

Measure: RESISTANCE At: LH FRONT DOOR LOCK MOTOR (Disconnected)		
Measure Between	Correct Result	For Diagnosis
Terminal 6 and Terminal 5	1 K ohm	See 1
<ul style="list-style-type: none"> If resistance is correct, replace the Unlock Inhibit Switch. <ol style="list-style-type: none"> Replace RH Front Door Lock Motor. 		

C: CONTROL UNIT UNLOCK TEST

Connect: A FUSED JUMPER At: CONTROL UNIT CONNECTOR (Connected)		
Jumper Between	Correct Result	For Diagnosis
6 (GN/BU) & Ground	Doors unlock	See 1
<ul style="list-style-type: none"> If the result is correct, repair/replace the switches and related wiring (see schematic). <ol style="list-style-type: none"> Replace the Central Locking Control Unit. 		

CIRCUIT DESCRIPTION

The Central Locking System is controlled by the Central Locking Control Unit. This unit senses when a lock switch is moved by a key, and sends the appropriate signal to drive the Motors. The Central Lock Control Unit controls the Door Locks, Gas Filler Lock and Trunk Lock. The unit also has an Inertia Switch which closes on impact greater than 5g. If in RUN or START the locks are then unlocked.

Lock

When the Key is inserted into a lock and turned clockwise, the Lock switch moves to LOCK and grounds terminal 7 of the Central Locking Control Unit. The unit activates the Lock Relay and applies voltage from Fuse 5 to the Lock Motor, which is grounded through the WT wire, Central Locking Control Unit and BR wire. The Lock Motor then pulls the lock down. As the motor runs, a switch is gradually moved from terminal 2 to terminal 6 of all but the Driver's Lock Motor. At terminal 6, the switch position prevents voltage from being applied to the motor. The door locks also control the Trunk Lock and Gas Filler Lock.

Unlock

When the key is turned counterclockwise, terminal G of the Central Locking Control Unit is grounded through the Lock Switch. The Central Locking Control Unit then activates the Unlock Relay and applies voltage from Fuse 27, through the WT wire to the Lock Motor. The motor is grounded through the BU wire, Central Locking Control Unit, and BR wire. The polarity is reversed and the motor pushes the lock up. As the motor runs, the switch is returned to terminal 2.

Unlock Inhibit


When the key is inserted into the Driver's Lock and turned clockwise past the LOCK position, the Unlock inhibit mechanism is engaged. This mechanically inserts a bar into the driver's lock and prevents unlocking through use of the Safety Catch Button. When in the Unlock Inhibit position, the Central Locking Unit is grounded at terminal 10. The unit then activates the Lock Relay, and voltage is applied to the motors through the Unlock Inhibit Switch and BK/WT wires. The motors are again acti-

vated and engage their Unlock Inhibit mechanisms.


Trunk Lock

The Trunk Lock operates in a manner similar to the Door Locks.


EARLY PRODUCTION




EARLY PRODUCTION




LATE PRODUCTION






EARLY PRODUCTION




LATE PRODUCTION






HORN

HOT IN ACCY. RUN OR START




CIGAR LIGHTER/GLOVE BOX LIGHT/AUTO-CHARGING FLASHLIGHT







WIPER/WASHER AND HEATED WASHER JETS




SPEEDOMETER/GAUGES/WARNING INDICATORS EARLY PRODUCTION




GAUGES/WARNING INDICATORS EARLY PRODUCTION




INSTRUMENT CLUSTER
PRINTED CIRCUIT




WARNING INDICATORS EARLY PRODUCTION





SERVICE INTERVAL INDICATOR EARLY PRODUCTION




SPEEDOMETER/GAUGES/WARNING INDICATORS LATE PRODUCTION




GAUGES/WARNING INDICATORS LATE PRODUCTION



WARNING INDICATORS LATE PRODUCTION



LATE PRODUCTION









Figure 1 - Above Rear View Mirror


ACTIVE CHECK CONTROL

1. When the Ignition Switch is initially placed in "Run," the Active Check Control Alarm Indicator flashes, and the Active Check Control Unit Brake Light LED and panel light illuminate for test purposes. Depressing the brake pedal clears the display.
2. When the Ignition Switch is placed in "Run," fault monitoring begins. To monitor the low beams, rear lights, or license lights, those circuits must be on. The brake lights are monitored only while the brake pedal is depressed.
3. When a fault occurs, the alarm indicator flashes, the appropriate LED indicator lights, and the panel light goes on for five seconds. Depressing the test button will clear the alarm indicator, but the LED fault indicator remains on.
4. To test the unit, depress the test button. The LED fault indicators and panel light should go on.











LIGHTS: DASH/TRANSMISSION RANGE


HOT IN RUN ONLY FROM UNLOADER RELAY





CONTROL





CONTINUED ON PAGE 6312-1






















HEATER AND A/C TEMPERATURE CONTROL





HEATER AND A/C BLOWER CONTROLS

HOT IN RUN ONLY FROM UNLOADER RELAY




A/C FRESH AIR DOOR CONTROL






WITH SOUND SYSTEM





WITH SOUND SYSTEM




WITHOUT SOUND SYSTEM


(For Component Locations See Page 211)








EARLY PRODUCTION



LATE PRODUCTION



7000-0 COMPONENT LOCATION VIEWS




Figure 1 - Rear of 535i Engine




Figure 3 - Center of 535i Engine




Figure 5 - Front of 535i Engine




Figure 2 - Front of 535i Engine




Figure 4 - Center of 535i Engine




Figure 6 - Center of 535i Engine




Figure 1 - Rear of 535i Engine




Figure 3 - Center of 528e Engine




Figure 5 - LH Rear of 528e Engine Compartment




Figure 2 - RH Front of 535i Engine




Figure 4 - RH Rear of 528e Engine Compartment




Figure 6 - LH Side of 528e Engine, Near Starter

7000-2 COMPONENT LOCATION VIEWS




Figure 1 - LH Rear of 528e Engine Compartment




Figure 3 - RH Rear of 528e Engine Compartment




Figure 5 - Front of 528e Engine




Figure 2 - Front of 528e Engine



Figure 4 - LH Front of 528e Engine Compartment




Figure 6 - Top RH Front of 528e Engine




Figure 1 - Below Throttle of 528e Engine




Figure 3 - LH Front of Engine Compartment (535i Shown, 528e Similar)




Figure 5 - Top of LH Front Wheel Well




Figure 2 - LH Front of Engine Compartment (535i Shown, 528e Similar)




Figure 4 - LH Front of Engine Compartment, Behind Battery




Figure 6 - LH Front of Engine Compartment, Above Battery

7000-4 COMPONENT LOCATION VIEWS




Figure 1 - RH Front of 535i Engine Compartment




Figure 3 - LH Rear of 535i Engine Compartment



Figure 5 - LH Rear of 535i Engine Compartment




Figure 2 - LH Side of 528e Radiator




Figure 4 - LH Rear of 535i Engine Compartment




Figure 6 - LH Rear of 528e Engine Compartment




Figure 1 - RH Front of Engine Compartment




Figure 3 - RH Front of Engine Compartment




Figure 5 - Inside Center of Hood (535i Shown, 528e Similar)




Figure 2 - RH Front of Engine Compartment




Figure 4 - RH Side of Engine Compartment, Inside Shock Tower (535i Shown, 528e Similar)




Figure 6 - In Front of Radiator (528e)




Figure 1 - Front of Radiator, Bottom of Auxiliary Fan Shield (535i)




Figure 3 - Bottom of 535i Engine Oil Pan




Figure 5 - LH Side of Transmission Near Shift Linkage (535i)




Figure 2 - Underneath Car, on Catalytic Converter




Figure 4 - RH Side of 528e Engine Oil Pan




Figure 6 - Under LH Side of Front Bumper



Figure 1 - Behind Wheel Dust Shield




Figure 3 - Under LH Side of Dash (535i)




Figure 5 - Behind LH Dash Panel




Figure 2 - Rear of Differential




Figure 4 - Behind LH Dash Panel (535i Shown, 528e Similar)




Figure 6 - Behind LH Dash Panel

7000-8 COMPONENT LOCATION VIEWS




Figure 1 - LH Foot Well




Figure 3 - Upper Part of Steering Column




Figure 5 - Behind LH Dash Panel




Figure 2 - Upper Part of Steering Column




Figure 4 - Behind LH Dash Panel (528e)




Figure 6 - Behind LH Dash Panel




Figure 1 - In LH Dash Panel




Figure 3 - Inside LH Front Door




Figure 5 - Under RH Side of Dash (535i, Manual Only)




Figure 2 - Behind LH Front Speaker




Figure 4 - Inside LH Front Door




Figure 6 - Under RH Side of Dash (528e)

7000-10 COMPONENT LOCATION VIEWS




Figure 1 - Inside Glove Box




Figure 3 - Behind RH Front Speaker




Figure 5 - LH Side of Upper Console




Figure 2 - Under RH Side of Dash, Beside Glove Box




Figure 4 - Inside RH Front Door



Figure 6 - LH Side of Upper Console




Figure 1 - RH Side of Upper Console




Figure 3 - Center Console, Near Shift Lever




Figure 5 - Underneath Seat




Figure 2 - Above Rear View Mirror (528e Shown, 535i Similar)



Figure 4 - Center Console (535i)




Figure 6 - Under LH Side of Rear Seat

7000-12 COMPONENT LOCATION VIEWS




Figure 1 - Under RH Side of Rear Seat




Figure 3 - In Rear Panel of Trunk




Figure 5 - Bottom RH Side of Trunk, Under Access Plate




Figure 2 - LH Front of Trunk (535i)




Figure 4 - RH Side of Trunk

INDEX


This index contains all the splices in the car, what harness each one is in, and the page that the splices appear on. The drawings after the index show how the harness is routed through the car and where the splices are located on the harness.

SPLICE	HARNESS	PAGE NUMBER	SPLICE	HARNESS	PAGE NUMBER
S100	FRONT	8000-5	S212	MIDDLE	8000-6
S101	FRONT	8000-5	S213	MIDDLE	8000-6
S102	FRONT	8000-5	S214	MIDDLE	8000-6
S103	FRONT	8000-5	S215	MIDDLE	8000-6
S104	FRONT	8000-5	S216	MIDDLE	8000-6
S105	ENGINE	NOT SHOWN	S217	MIDDLE	8000-6
S106	ENGINE	8000-8	S218	MIDDLE	8000-6
S107	ENGINE	8000-8	S219	MIDDLE	8000-6
S109	ENGINE	8000-8	S220	MIDDLE	8000-6
S110	ENGINE	8000-8	S221	MIDDLE	8000-6
S112	ENGINE	8000-8	S222	CRUISE CONTROL	8000-7
S113	ENGINE	8000-8	S223	CRUISE CONTROL	8000-7
S118	HEATED WASHER JETS	NOT SHOWN	S224	CRUISE CONTROL	8000-7
S119	HEATED WASHER JETS	NOT SHOWN	S225	A/C	8000-7
S120	FRONT	8000-5	S226	A/C	8000-7
S200	MIDDLE	8000-6	S227	A/C	8000-7
S201	MIDDLE	8000-6	S228	A/C	8000-7
S202	MIDDLE	8000-6	S229	A/C	8000-7
S203	MIDDLE	8000-6	S231	MIDDLE	8000-6
S204	MIDDLE	8000-6	S232	POWER SEATS	NOT SHOWN
S205	MIDDLE	8000-6	S233	POWER SEATS	NOT SHOWN
S206	MIDDLE	8000-6	S234	MIDDLE	NOT SHOWN
S207	MIDDLE	8000-6	S235	REAR	NOT SHOWN
S208	MIDDLE	8000-6			
S209	MIDDLE	8000-6			
S210	MIDDLE	8000-6			
S211	MIDDLE	8000-6			


INDEX

SPLICE	HARNESS	PAGE NUMBER	SPLICE	HARNESS	PAGE NUMBER
S300	REAR	8000-3	S409	ELEC LOCK/ CENTRAL LOCK	NOT SHOWN
S303	REAR	8000-3	S410	ELEC LOCK/ CENTRAL LOCK	8000-2
S304	REAR	8000-3	S411	ELEC LOCK/ CENTRAL LOCK	8000-2
S305	REAR	8000-3	S412	ELEC LOCK/ CENTRAL LOCK	8000-2
S306	REAR	8000-3	S414	ELEC LOCK/ CENTRAL LOCK	8000-2
S308	REAR	8000-3	S415	ELEC LOCK/ CENTRAL LOCK	8000-2
S309	REAR	8000-3	S416	ELEC LOCK/ CENTRAL LOCK	8000-2
S310	REAR	8000-3	S417	ELEC LOCK/ CENTRAL LOCK	8000-2
S311	REAR	8000-3	S418	PASSENGER DOOR	8000-4
S312	REAR	8000-3	S420	RADIO	NOT SHOWN
S313	REAR	8000-3	S500	DRIVER'S DOOR	8000-4
S314	REAR	8000-3	S501	DRIVER'S DOOR	8000-4
S315	REAR	8000-3	S502	DRIVER'S DOOR	8000-4
S316	REAR	8000-3	S503	DRIVER'S DOOR	8000-4
S317	REAR	8000-3	S504	DRIVER'S DOOR	8000-4
S318	REAR	8000-3	S600	SUNROOF	NOT SHOWN
S319	REAR	8000-3	S601	SUNROOF	NOT SHOWN
S320	REAR	8000-3			
S400	ELEC LOCK/ CENTRAL LOCK	8000-2			
S401	ELEC LOCK/ CENTRAL LOCK	8000-2			
S402	ELEC LOCK/ CENTRAL LOCK	8000-2			
S403	ELEC LOCK/ CENTRAL LOCK	8000-2			
S404	ELEC LOCK/ CENTRAL LOCK	8000-2			
S405	ELEC LOCK/ CENTRAL LOCK	8000-2			
S406	ELEC LOCK/ CENTRAL LOCK	8000-2			
S407	ELEC LOCK/ CENTRAL LOCK	8000-2			
S408	ELEC LOCK/ CENTRAL LOCK	8000-2			


CENTRAL LOCKING HARNESS




REAR HARNESS




DOOR HARNESS




FRONT HARNESS




MIDDLE HARNESS





ENGINE HARNESS



8500-0 CONNECTOR VIEWS

DIAGNOSTIC CONNECTOR




Figure 1 - Top Of Engine

PIN	WIRE SIZE	WIRE COLOR	CIRCUIT AND COMPONENT CONNECTED
1	1.5	BR	Ground Distribution, G103.
4	.5	BR/VI	Gauges/Warning Indicators, Coolant Temperature Sender.
6	.5	WT/BK	Not Used.
7	.5	WT/BU	Service Interval Indicator, Service Interval Processor (Reset).
8	.5	YL	Ignition, TDC Sensor.
9		SHIELD	Ignition, TDC Sensor.
10	.5	BK	Ignition, TDC Sensor.
11	2.5	BK/YL	Start, Start Signal.
12	.75	BU	Charge System, Alternator.
13	1	GN	Ignition, Ignition Coil.
14	2.5	RD	Charge System, Alternator.
15	1.5	GN/YL	Idle Speed, Idle Speed Control Unit.

ACCESSORY CONNECTOR







Figure 1 - Under Left Side Of Dash


8500-2 CONNECTOR VIEWS




Wiring Face
ABS ELECTRONIC CONTROL UNIT




Wiring Face
ACTIVE CHECK CONTROL UNIT




Wiring Face
AMPLIFIER




Wiring Face
ABS HYDRAULIC UNIT




Wiring Face
AIR DOOR CONTROL




Wiring Face
AUTOMATIC TRANSMISSION RANGE SWITCH




Mating Face
A/C SELECTOR SWITCH




Mating Face
AIR FLOW METER




Wiring Face
AUXILIARY FAN




Wiring Face
AUXILIARY FAN RELAY




Wiring Face
BLOWER SPEED SWITCH (C2)




Wiring Face
CHIME MODULE (C2)




Wiring Face
BAROMETRIC PRESSURE SENSOR




Wiring Face
CENTRAL LOCKING CONTROL UNIT




Wiring Face
CRUISE CONTROL



Wiring Face
BLOWER SPEED SWITCH





















Wiring Face
CHIME MODULE (C1)












Wiring Face
DASH WARNING DISPLAY


8500-4 CONNECTOR VIEWS






8500-6 CONNECTOR VIEWS






Wiring Face
MIRROR




Wiring Face
ON BOARD COMPUTER MODULE




Wiring Face
OUTSIDE MIRROR




Wiring Face
MIRROR CONTROL SWITCH




Wiring Face
ON BOARD COMPUTER RELAY BOX (C1)




Wiring Face
POTENTIOMETER



Mating Face
MOTRONIC CONTROL UNIT



Wiring Face
ON BOARD COMPUTER RELAY BOX (C2)




Wiring Face
POWER SEAT CONTROL UNIT (C2)


8500-8 CONNECTOR VIEWS




Wiring Face
PROGRAM SWITCH (C1)




Wiring Face
REAR LIGHT ASSEMBLY




Wiring Face
REAR CHECK LIGHTS CHECK RELAY (C2)




Wiring Face
PROGRAM SWITCH (C2)




Wiring Face
REAR LIGHTS CHECK RELAY




Wiring Face
REFERENCE POINT SENSOR




Wiring Face
REAR DEFOGGER




Wiring Face
REAR LIGHTS CHECK RELAY (C1)




Wiring Face
SEAT BELT WARNING TIMER




Wiring Face
SEAT SWITCHES BACK
& SEAT CUSHIONS




Wiring Face
START RELAY




Wiring Face
THROTTLE POSITION SENSOR




Wiring Face
SEAT SWITCHES FRONT
& REAR HEIGHT




Wiring Face
SUNROOF MOTOR (CI)




Mating Face
TRANSMISSION CONTROL UNIT
(535i ONLY)



Wiring Face
SERVICE REMINDER SWITCH




Wiring Face
SUNROOF SWITCH




Wiring Face
TRANSMISSION RANGE DISPLAY


8500-10 CONNECTOR VIEWS




Wiring Face
WIPER MOTOR




Wiring Face
C101




Wiring Face
C103
(535i only)




Wiring Face
WIPER SWITCH




Wiring Face
C102



Wiring Face
C113




Wiring Face
WINDOW SWITCHES




Wiring Face
C103
(528e only)




Wiring Face
C114




Wiring Face
C141




Wiring Face
C201




Wiring Face
C206




Wiring Face
C152




Wiring Face
C202




Wiring Face
C209



Wiring Face
C200




Wiring Face
C205




Wiring Face
C210


8500-12 CONNECTOR VIEWS




Wiring Face
C214




Wiring Face
C250




Wiring Face
C401




Wiring Face
C238
(535i only)




Wiring Face
C320




Wiring Face
C402




Wiring Face
C240




Wiring Face
C400




Wiring Face
C500



Wiring Face
C501



Wiring Face
C502



Wiring Face
C550

9000-0 COMPONENT LOCATION CHART

COMPONENTS		Page-Figure
0 Degrees C Temperature Switch (528e)	On right inlet of heater blower housing	7000- 1-4
0 Degrees C Temperature Switch (535i)	On right inlet of heater blower housing	7000- 4-3
A/C Compressor Clutch	On front of A/C compressor	
ABS Electronic Control Unit	Under RH side of dash	7000- 9-5
ABS Hydraulic Unit	RH front of engine compartment	7000- 5-1
Active Check Control Unit	Above rear view mirror	7000-11-2
Air Flow Meter (528e)	LH side of engine	7000- 1-5
Air Flow Meter (535i)	RH side of engine	7000- 1-1
Amplifier	LH side of trunk, below rear shelf	7000-12-2
Auto-Charging Flashlight	In glove box	7000-10-1
Auto. Trans. Range Switch	At base of shift lever	7000-11-3
Auxiliary Fan In-Line Diode	RH side of engine compartment, in harness, behind headlights	
Auxiliary Fan Motor	In front of radiator	7000- 5-6
Auxiliary Fuel Pump	In fuel tank, below trunk RH side access plate	7000-12-5
Auxiliary Fuse	On power distribution box	7000- 3-2
B/C Horn Diode	LH front of engine compartment, behind battery	7000- 3-4
Backup Light Switch	On LH side of transmission	
Barometric Pressure Sensor	On RH front of air cleaner housing	7000- 2-4
Blower Speed Switch	RH side of upper console	
Board Computer Horn	LH front of engine compartment, behind battery	7000- 3-4
Brake Accumulator Pressure Switch	LH rear of engine compartment	7000- 4-5
Brake Fluid Level Switch (528e)	LH rear of engine compartment, on brake fluid reservoir	7000- 1-5
Brake Fluid Level Switch (535i)	LH rear of engine compartment, on brake fluid reservoir	7000- 4-5
Brake Switch	Above brake pedal	7000- 8-6
Central Locking Control Unit	Behind RH kick panel, above speaker	7000-10-3
Chime Module	Under LH side of dash	7000- 8-5
Clutch Switch	Above clutch pedal	
Cold Start Valve (528e)	RH side of engine, above valve cover	7000- 2-3
Cold Start Valve (535i)	Between intake ports 3 and 4	7000- 0-4
Combination Switch	On LH side of steering column	7000- 8-2
Coolant Level Switch (528e)	RH side of engine compartment, in coolant reservoir	7000- 2-3
Coolant Level Switch (535i)	LH rear of engine compartment, in coolant reservoir	7000- 3-3
Coolant Temperature Sender (528e)	Front of engine, on thermostat housing	7000- 2-6
Coolant Temperature Sender (535i)	Front of engine, on thermostat housing	7000- 0-5
Coolant Temperature Sensor (528e)	Front of engine, top of thermostat housing	7000- 2-6
Coolant Temperature Sensor (535i)	Front of engine, on thermostat housing	7000- 0-5

COMPONENTS

		Page-Figure
Coolant Temperature Switch	Front of engine, top of thermostat housing	7000- 2-5
Cruise Control Actuator	LH front of engine compartment, in front of power distribution box	7000- 3-6
Cruise Control Control Unit	Under LH side of dash	7000- 8-5
Cruise Control Switch	On RH side of steering column	7000- 8-3
Diagnostic Connector (528e)	LH side of engine, on intake manifold	7000- 2-4
Diagnostic Connector (535i)	Top front of engine	7000- 0-2
Door Lock Motors	Center rear of respective door	7000-10-4
Engine Speed Sensor (528e)	On transmission bell housing	7000- 1-6
Engine Speed Sensor (535i)	On transmission bell housing	7000- 0-1
Evaporator Blower Motor	Under center of dash	7000-11-1
Evaporator Blower Resistors	On RH side of evaporator housing	7000-11-1
Evaporator Temperature Regulator	LH side of upper console	7000-10-6
Evaporator Temperature Sensor	In evaporator, above evaporator blower motor	
Fader Control	LH side of upper console	7000-10-5
Flasher	Upper part of steering column	7000- 8-2
Fuel Injectors (528e)	Mounted in intake port of each cylinder	7000- 1-3
Fuel Injectors (535i)	Mounted in intake port of each cylinder	7000- 0-6
Fuel Pump Relay	On power distribution box	7000- 3-3
Fuel Tank Sender	In fuel tank, below trunk, RH side access plate	7000-12-5
Gas Filler Lock Motor	In trunk, right of power antenna	7000-12-4
Hazard Switch	To right of instrument cluster	
Heater Blower Motor	Below windshield, behind cover panel	
Heater Blower Resistors	Below heater cover motor	
Heater Regulator	Behind A/C selector switch	7000-10-5
Heater Temperature Sensor	LH side of upper console	7000-10-6
Heater-A/C Panel Lights	Behind heater-air conditioning control panel	
High Pressure Cut-Out Switch	RH front of engine compartment, on receiver-drier	7000- 5-2
High Speed Relay	Attached to power distribution box	7000- 3-2
High Speed Temperature Switch (528e)	On upper LH side of radiator (red terminals)	7000- 4-2
High Speed Temperature Switch (535i)	On upper RH side of radiator (red terminals)	7000- 4-1
Horn Brush/Slip Ring	Below hub of steering wheel	
Horn Switches	In each spoke on steering wheel	
Hydraulic Pressure Switch	LH rear of engine compartment	7000- 4-4
Idle Control Valve	Top rear RH side of engine	7000- 1-4
Idle Speed Actuator	Top center of engine	7000- 1-1
Idle Speed Control Unit	Under RH side of dash, above glove box	7000- 9-6
Ignition Coil	RH front of engine compartment	7000- 5-3
Ignition Key Switch	In upper part of steering column	

9000-2 COMPONENT LOCATION CHART

COMPONENTS

Page-Figure

Ignition Switch	Upper part of steering column	
Interior Light Timer Control	Under LH side of dash	7000- 7-4
Interior Temperature Sensor	Mounted in left, under dash cover	7000- 7-5
Kickdown Switch	Underneath accelerator pedal	7000- 8-1
Lock Heater	In LH front door	7000- 9-3
Lock Heater Control Unit	In LH front door	7000- 9-3
Low Beam Check Relay	Attached to power distribution box	7000- 3-2
Main Fuel Pump	Forward and right of differential housing	
Main Relay	On power distribution box	7000- 3-3
Mirror Control Switch	On LH front door	
Motor Relay	Behind header, above rear view mirror	
Motronic Control Unit	Under RH side of dash, above glove box	7000- 9-5
Normal Speed Blower Resistor (528e)	In front of radiator, on top of auxiliary fan shield	7000- 5-6
Normal Speed Blower Resistor (535i)	In front of radiator, on bottom of auxiliary fan shield ..	7000- 6-1
Normal Speed Coolant Temperature Switch	On upper LH side of radiator (white terminals)	7000- 4-2
Normal Speed Coolant Temperature Switch (535i) ..	On upper RH side of radiator (white terminals)	7000- 4-1
Normal Speed Relay	Attached to power distribution box	7000- 3-2
Oil Level Sensor (528e)	Bottom of engine oil pan	7000- 6-4
Oil Level Sensor (535i)	Bottom of engine oil pan	7000- 6-3
Oil Pressure Switch (528e)	RH side of engine, below oil filter	7000- 6-4
Oil Pressure Switch (535i)	Rear of engine, in cylinder head	7000- 0-1
On-Board Computer Module	On dash, right of instrument cluster	
On-Board Computer Relay Box	Under LH side of dash	7000- 8-5
Outside Temperature Sensor	Under left side of front bumper	7000- 6-6
Oxygen Sensor (528e)	In exhaust manifold, at rear of engine	7000- 2-1
Oxygen Sensor (535i)	On catalytic convertor	7000- 6-2
Oxygen Sensor Heater Relay	On power distribution box	7000- 3-3
Parking Brake Switch	In shift console, at base of parking brake	
Power Antenna	RH side of trunk	7000-12-4
Power Distribution Box	On LH front wheel well	7000- 3-2
Power Window Circuit Breaker	Mounted in left, under dash cover	7000- 9-1
Power Window Relay	Under LH side of dash	7000- 7-4
Program Selector Switch	Center console, near shift lever	7000-11-4
Rear Lights Check Relay	Mounted on trunk lock support	7000-12-3
Reference Point Sensor (528e)	On transmission bell housing	7000- 1-6
Reference Point Sensor (535i)	On transmission bell housing	7000- 0-1
Right Front Door Micro Switch	Inside RH front door, mounted on door lock	7000-10-4
Safety Switch	On shift console, next to shift lever	7000-11-3
Seat Controllers	Under respective seat, on frame	7000-11-5

COMPONENTS

Page-Figure

Seatbelt Switch In driver’s seatbelt buckle

Seatbelt Warning Timer Under LH side of dash 7000- 7-4

Service Reminder Switch Behind LH dash panel, mounted on RH side of steering column 7000- 8-4

Speed Detector Behind wheel dust shield 7000- 7-1

Speedometer Sender In rear of differential 7000- 7-2

Start Relay On connector bracket, under LH side of dash 7000- 7-4

Starter Lower rear LH side of engine

Sunroof Motor Behind header, above rear view mirror

Sunroof Switch Above rear view mirror

TDC Sensor (528e) Above crankshaft vibration damper 7000- 2-2

TDC Sensor (535i) Above crankshaft vibration damper 7000- 1-2

Thermo-Time Switch (528e) Front of engine, top of thermostat housing 7000- 2-5

Thermo-Time Switch (535i) Front of engine, top of thermostat housing 7000- 0-5

Throttle Position Sensor Top of engine, front of air intake assembly 7000- 0-3

Throttle Position Switch Top of engine, front of air intake assembly 7000- 0-3

Throttle Switch Top LH side of engine, below throttle body 7000- 3-1

Transmission Control Unit Under LH side of dash 7000- 7-3

Trunk Lock Motor In rear panel of trunk 7000-12-3

Unlock Inhibit Switch In LH front door, on door lock 7000- 9-4

Washer Fluid Level Switch RH front of engine compartment, in washer reservoir 7000- 5-3

Washer Jet Heaters Attached to washer jet nozzles 7000- 5-5

Washer Jet Heaters On washer jet nozzles 7000- 5-5

Washer Pump RH front of engine compartment, in washer reservoir 7000- 5-3

Water Shut-Off Valve (528e) Below brake master cylinder 7000- 4-6

Water Shut-Off Valve (535i) LH rear of engine compartment 7000- 4-4

Window Console Switches On shift console, next to shift lever 7000-11-3

Window Motors In each door 7000- 9-4

Wiper Motor Above brake master cylinder

Wiper/Washer Switch On RH side of steering column 7000- 8-2

CONNECTORS

C101 (17 pin) (528e) Engine compartment, on RH side of power distribution box 7000- 3-2

C102 (7 pin) In power distribution box 7000- 3-5

C103 (6 pin) RH side of dash, near motronic control unit 7000- 9-5

C104 (2 pin) RH side of dash, near motronic control unit 7000- 9-6

C105 (1 pin) (528e) At RH wheel well, below coolant reservoir

C105 (1 pin) (535i) At RH wheel well, below coolant reservoir

C107 (2 pin) LH front of engine compartment 7000- 3-6

9000-4 COMPONENT LOCATION CHART

COMPONENTS		Page-Figure
C108 (2 pin)	RH front of engine compartment	7000- 5-3
C110 (2 pin)	RH front of engine compartment	7000- 5-3
C113 (3 pin) (528e)	Forward of radiator, on auxiliary fan shield	
C113 (535i)	LH side of engine compartment, below headlights	
C131 (1 pin)	RH side of dash, near motronic control unit	7000- 9-5
C132 (1 pin)	RH side of dash, near motronic control unit	7000- 9-5
C141	Rear of engine, in exhaust manifold	
C150 (2 pin) (528e)	LH side of engine compartment, in shock tower	7000- 1-5
C150 (2 pin) (535i)	LH side of engine compartment, under master cylinder	
C151 (2 pin)	RH side of engine compartment, in shock tower	7000- 5-4
C152 (8 pin)	Mounted on LH side of transmission, near shift linkage	7000- 6-5
C200 (10 pin)	On LH side of steering column	7000- 7-6
C201 (6 pin)	On LH side of steering column	7000- 7-6
C202 (13 pin)	On LH side of steering column	7000- 7-6
C203 (2 pin)	At upper end of steering column	
C204 (13 pin)	On LH side of heater/evaporator housing	7000-10-6
C206 (29 pin)	On connector bracket, under LH side of dash	7000- 7-4
C208 (2 pin)	Near clutch pedal	
C209 (7 pin)	Under LH side of dash	7000- 8-6
C210 (4 pin)	On LH side of steering column	7000- 7-6
C212 (1 pin)	Under LH side of dash, taped to harness	
C213 (1 pin)	Under LH side of dash	7000- 8-6
C214 (6 pin)	Behind center of dash, near heater blower	
C215 (2 pin)	Behind radio	
C216 (2 pin)	Behind radio	
C217 (2 pin)	Behind radio	
C218 (2 pin)	Behind radio	
C219 (3 pin) (528e)	Taped to harness, near LH shock tower	7000- 1-5
C219 (3 pin) (535i)	Taped to harness, near LH shock tower	7000- 4-4
C220 (1 pin)	Under LH side of dash	
C235 (1 pin)	Under LH side of dash, near on-board computer	
C238 (11 pin)	Under RH side of dash, above glove box	7000-10-2
C240 (6 pin)	Under RH side of dash, above glove box	7000-10-2
C250 (13 pin)	Under center of rear seat	7000-12-1
C300 (2 pin)	Near trunk light	
C301 (2 pin)	In center console, ahead of shift lever	
C302 (Accessory Connector)	Under LH side of dash	7000- 7-4
C303 (2 pin)	In headliner, near LH dome light	

COMPONENTS

		Page-Figure
C320 (20 pin)	LH side of trunk, below rear shelf	7000-12-2
C351 (2 pin)	Under RH side of rear seat, behind grommet	
C352 (2 pin)	Under LH side of rear seat, behind grommet	
C400 (13 pin)	Behind LH front speaker	7000- 9-2
C401 (13 pin)	Behind RH front speaker	7000-10-3
C402 (7 pin)	In LH B pillar	
C403 (7 pin)	In RH B pillar	
C404 (5 pin)	In bottom rear of LH front door	
C405 (2 pin)	In trunk, near trunk lock	
C500 (6 pin)	Behind LH front speaker	7000- 9-2
C501 (4 pin)	Behind LH front speaker	7000- 9-2
C502 (4 pin)	Behind RH front speaker	7000-10-3
C503 (8 pin)	In LH front door	7000- 9-4
C550 (2 pin)	Under center console	
C551 (2 pin)	Under center console	
C560 (2 pin)	In LH front door	

GROUNDS

G102 (Main Body Ground)	LH front of engine compartment, on fender well	7000- 3-6
G103 (Engine Ground) (528e)	Front of engine, under diagnostic connector	7000- 2-4
G103 (Engine Ground) (535i)	Top rear of engine	7000- 1-1
G200 (Front Interior Ground)	Under LH side of dash, near brake bracket	7000- 7-6
G201 (Steering Column Ground)	Upper part of steering column	7000- 8-3
G301 (Rear Interior Ground)	Under LH side of rear seat	7000-11-6
G302	RH side of trunk	7000-12-4
G600	Near sunroof switch	

SECTION B: 535i

1986 BMW 535i Electrical Troubleshooting Manual

CONTENTS

How To Use This Manual	3
Symbols	4
Wire Size Conversion Chart	3
Systematic Troubleshooting	6
Section B: 535i Schematic Diagrams	
535i Index	2
Diagnostic Connector	8500-0
Power Distribution Box	0670-0
Fuse Data	0670-1
Component Location Chart	9000-0
Component Location Views	7000-0
Splice Location Views	8000-0

2 INDEX (535i)

Alphabetical Listing of Electrical Circuits

Active Check Control	6216-0	Ignition	1360-0	– Headlights (Control)	6312-0
Air Conditioning		Ignition Key Warning	6131-0	– Headlights (Power)	6312-1
– Blower Controls	6413-0	Indicators		– Interior	6330-0
– Temperature Control	6411-0	– Active “Check” Control Alarm.	6216-2	– Instrument Cluster	6210-0
AntiLock Brake System	3450-0	– “Brake Lights” Fault	6216-1	– License	6320-0
Auto-Charging Flashlight	6100-2	– “Brake Lining” Wear Warning	3435-0	– Light Switch Details	6300-0
Auxiliary Fan	6454-0	– “Brake” Warning	6210-2	– Rear Marker	6320-0
Body Electrical	6100-0	– Charge	6210-0	– Stop Lights	6325-0
Brake Lining Warning	3435-0	– “Coolant” Level Fault	6216-2	– Tail	6314-0
Central Locking	5126-0	– “Engine Oil” Fault	6216-2	– Transmission Range	6300-2
Charging System	1230-0	– Fasten Seatbelts	6216-2	– Trunk	6320-0
Cigar Lighter	6100-2	– Fog Lights	6312-1	– Turn	6313-0
Connector Views	8500-0	– High Beam	6312-0	Injection Electronics	1360-0
Cruise Control	6571-0	– Inspection	6210-3	On-Board Computer	6581-0
Electronic Transmission Control	2460-0	– LH Turn	6313-0	Power Antenna	6500-0
Engine Block Diagram	1250-0	– “License Plate” Fault	6216-1	Power Distribution	0670-2
Fuel Control	1360-6	– “Low Beam” Fault	6216-0	Power Distribution Box	0670-0
Fuel Delivery	1360-2	– Low Fuel Warning	6210-1	Power Mirrors	5116-0
Fuel Gauge	6210-1	– Oil Pressure Warning	6210-1	Power Seats	5200-0
Fuse Data	0670-1	– Oil Service	6210-3	Power Windows	5133-0
Fuse Details	0670-4	– “Park Brake”	6210-1	Radio	6500-0
– Fuse 4	0670-5	– Rear Lights Fault	6314-0	Rear Defogger	6100-1
– Fuse 5	0670-8	– RH Turn	6313-0	Seatbelt Warning	6131-0
– Fuse 6	0670-4	– “Washer Fluid” Fault	6216-2	Service Interval Indicator	6210-3
– Fuse 11	0670-6	Injection Electronics	1360-0	Speedometer	6210-0
– Fuse 12	0670-7	Lights		Splice Locations	8000-0
– Fuse 13	0670-5	– A/C Control	6300-3	Start	
– Fuse 14	0670-7	– Ashtray	6300-3	– Automatic	1240-0
– Fuse 17	0670-5	– BackUp	6322-0	– Manual	1240-1
Gauges	6210-0	– Brake	6325-0	Sunroof	5413-0
Ground Distribution	0670-9	– Cigar Lighter	6300-3	Tachometer	6210-0
Heated Door Locks	6100-1	– Dash	6300-2	Temperature Gauge	6210-1
Heating		– Fog	6312-1	Warnings	
– Blower Controls	6413-0	– Front Marker	6314-0	– Ignition Key	6131-0
– Temperature Control	6411-0	– Front Park	6314-0	– Seatbelt	6130-0
Horns	6100-0	– Glove Box	6100-2	Washer Jet Heaters	6160-0
Idle Speed Control	1360-2	– Hazard Warning	6313-0	Wiper/Washer	6160-0

POWER DISTRIBUTION BOX

NOTE
 On some cars, the position of the side mounted relays may be interchanged on their respective sides. Check relay wire colors for positive identification.






Figure 1- Top Of Left Front Wheel Well

Fuse No.	Size/Color	Circuit Name
1	16A (RD)	Fuel Delivery.
2	8A (WT)	Active Check Control (also fuses 5, 6, 9, 10, 11, 12); Headlights (RH Low Beam).
3	8A (WT)	Active Check Control (also fuses 5, 6, 9, 10, 11, 12); Headlights (LH Low Beam).
4	25A (BU)	Cigar Lighter; Power Seats; Radio/Power Antenna (also fuses 5, 12).
5	8A (WT)	Active Check Control (also fuses 2, 3, 6, 9, 10, 11, 12); Central Locking; Electronic Transmission Control; Glove Box/Auto-Charging Flashlight; Heated Door Locks; Ignition Key Warning/Seatbelt Warning (also fuse 6); Lights: Turn/Hazard Warning (also fuse 11); Lights: Trunk; On-Board Computer (also fuses 6, 12); Radio/Power Antenna (also fuses 4, 12); Service Interval Indicator (also fuse 6).
6	8A (WT)	Active Check Control (also fuses 2, 3, 5, 9, 10, 11, 12); Back Up Lights/Transmission Range Lights; Cruise Control (also fuse 12); Fog Lights (also fuses 15, 16); Fuel Control; Gauges; Heater/Air Conditioning (also fuse 14); Idle Speed Control; Ignition; Interior Lights (also fuse 5); On-Board Computer (also fuses 5, 12); Power Mirrors; Power Windows (also Power Window Circuit Breaker); Seatbelt Warning (also fuse 5); Service Interval Indicator (also fuse 5); Speedometer; Warning Indicators (also fuse 15).
7	8A (WT)	Headlights (RH High Beams).


Fuse No.	Size/Color	Circuit Name
8	8A (WT)	Headlights (LH High Beams).
9	8A (WT)	Active Check Control (also fuses 2, 3, 5, 6, 10, 11, 12); Dash Lights (also fuses 6, 14); Lights: Front Park/Front Marker/Tail: (also fuse 10); Lights: Rear Marker/License: (also fuse 10).
10	8A (WT)	Active Check Control (also fuses 2, 3, 5, 6, 9, 11, 12); Lights: Front Park/Front Marker/Tail (also fuse 9); Lights: Rear Marker/License (also fuse 9).
11	16A (RD)	Active Check Control (also fuses 2, 3, 5, 6, 9, 11, 12); Horn; Lights: Turn/Hazard Warning (also fuse 5); Wiper/Washer and Heater Washer Jets.
12	8A (WT)	Active Check Control (also fuses 2, 3, 5, 6, 9, 10, 11); Cruise Control; Radio (also fuses 4, 5); Stop Lights; On-Broad Computer (also fuses 5, 6); Power Antenna (also fuses 4, 5).
13	16A (RD)	Rear Defogger; Sunroof.
14	25A (BU)	Auxiliary Fan (also fuse 17); Dash Lights (also fuses 6, 9); Heater/Air Conditioning (also fuse 6).
15	8A (WT)	Fog Lights (RH).
16	8A (WT)	Fog Lights (LH).
17	25A (BU)	Auxiliary Fan (also fuse 14).
Power Window Circuit Breaker	25A (BU)	Power Windows (also fuse 6).




FUSE DETAILS: FUSE 6



FUSE DETAILS: FUSES 4, 17 and 13




FUSE DETAILS: FUSE 11




FUSE DETAILS: FUSES 12 AND 14



HOT IN RUN ONLY FROM UNLOADER RELAY





HOT IN ACCY, RUN, OR START





GROUND DISTRIBUTION (G102, AND G301)




GROUND DISTRIBUTION (G102)




GROUND DISTRIBUTION (G200)




GROUND DISTRIBUTION (G200 AND G106)







MANUAL ONLY




AUTOMATIC ONLY




AUTOMATIC ONLY




IGNITION (MANUAL ONLY)




FUEL DELIVERY AND IDLE SPEED CONTROL (AUTOMATIC ONLY)




FUEL DELIVERY AND IDLE SPEED CONTROL (AUTOMATIC ONLY)




FUEL DELIVERY AND IDLE SPEED CONTROL (MANUAL ONLY)





FUEL CONTROL (AUTOMATIC ONLY)



FUEL CONTROL (MANUAL ONLY)







TROUBLESHOOTING HINTS

- Try the following check before doing the System Check.
 Check Fuse 6 if all the Transmission Range Display bulbs do not operate.
- Go to System Check for a guide to normal operation.
- Go to System Diagnosis for diagnostic tests.

SYSTEM CHECK

- Use the System Check Table as a guide to normal operation.
- Refer to System Diagnosis for a list of symptoms and diagnostic steps.

SYSTEM CHECK TABLE

ACTION	NORMAL OPERATION
Turn the Ignition Switch to RUN	The Transmission Fault Indicator flashes twice, then stays on
Set the Program Selector Switch to "321"	The "321" Indicator lights
Crank the engine	The Program Selector Switch returns to E
Start the engine	The Transmission Fault Indicator goes out with the engine running
Drive the car with the Program Selector Switch in "321"	The car operates in selected gear only (first, second, or third gear)

COMPONENT LOCATION

Page-Figure

Auto. Trans. Range Switch	At base of shift lever	7000-11-3
Kickdown Switch	Underneath accelerator pedal	7000- 8-1
Main Relay	On power distribution box	7000- 3-3
Motronic Control Unit	Under RH side of dash, above glove box	7000- 9-5
Power Distribution Box	On LH front wheel well	7000- 3-2
Program Selector Switch	Center console, near shift lever	7000-11-4
Throttle Position Sensor	Top of engine, front of air intake assembly	7000- 0-3
Transmission Control Unit	Under LH side of dash	7000- 7-3
C152 (8 pin)	Mounted on LH side of transmission, near shift linkage	7000- 6-5
C206 (29 pin)	On connector bracket, under LH side of dash	7000- 7-4
C238 (11 pin)	Under RH side of dash, above glove box	7000-10-2
C301 (2 pin)	In center console, ahead of shift lever	
G102 (Main Body Ground)	LH front of engine compartment, on fender well	7000- 3-6

Drive the car with the Program Selector Switch in S	First, second, and third gears are kept selected up to full engine speed. Fourth gear (overdrive) is not selected
Drive the car with the Program Selector Switch in E	Transmission shifts at lower engine speeds and a fourth gear (overdrive) is available

- Refer to System Diagnosis when a result is not normal.

SYSTEM DIAGNOSIS

- Do the tests listed for your symptom in the Symptom Table below.
- Tests follow the Symptom Table.
- Perform all tests in the order listed in the Symptom Table.

SYMPTOM TABLE

SYMPTOM	DO TEST
Transmission Fault Indicator does not flash when the Ignition Switch is turned to RUN and lights when the engine is running	A: Transmission Control Unit 5 Volt Power and Ground Test
Transmission Fault Indicator flashes when the Ignition Switch is turned to RUN and lights with the engine running	C: Engine Speed and Fuel Rate Input Test D: Hydraulic Pressure Regulator and Solenoid Test
Transmission Fault Indicator does not light with the Ignition Switch in RUN and the engine not running	B: Transmission Control Unit Ignition Power Test G: Transmission Fault Indicator Test
Program Selector Switch does not return to E when the engine is cranked	F: Program Selector Switch Return Test
"321" Indicator does not light when the Program Selector Switch is set to "321", but Transmission operates in the 321 mode	H: "321" Indicator Test

Transmission does not operate in selected program and the Transmission Fault Indicator is off with the engine running	I: Program Selector Switch Continuity Test
Kickdown function is inoperative	K: Kickdown Switch Test
Shift Points are inaccurate or rough and the Transmission Fault Indicator is off with the engine running	L: Gear Input Test M: Throttle Position Sensor and Wide Open Throttle Output Test J: Transmission Speed Sensor Test

- If your symptom does not appear in the Symptom Table, perform all of the following tests.

A: TRANSMISSION CONTROL UNIT 5 VOLT POWER AND GROUND TEST

Measure: VOLTAGE At: TRANSMISSION CONTROL UNIT CONNECTOR (Connected) Condition: • Ignition Switch: RUN		
Measure Between	Correct Voltage	For Diagnosis
24 (BR/GN) & Ground	Approximately 5 Volts	See 1
24 (BR/GN) & 19 (BR)	Approximately 5 Volts	See 2
24 (BR/GN) & 5 (BR)	Approximately 5 Volts	See 2
<ul style="list-style-type: none"> • If all the results are correct, replace the Transmission Control Unit. <ol style="list-style-type: none"> 1. Go to Test E: Motronic Control Unit Test. 2. Check/repair the BR wire for an open (see schematic). 		

B: TRANSMISSION CONTROL UNIT IGNITION POWER TEST

Measure: VOLTAGE At: TRANSMISSION CONTROL UNIT CONNECTOR (Connected) Condition: • Ignition Switch: RUN		
Measure Between	Correct Voltage	For Diagnosis
35 (RD/BU) & Ground	Battery	See 1
<ul style="list-style-type: none"> • If the result is correct, go to the Symptom Table. <ol style="list-style-type: none"> 1. Check/repair the RD/BU wire to the Main Relay for an open (see schematic). 		

C: ENGINE SPEED AND FUEL RATE INPUT TEST

Measure: VOLTAGE At: TRANSMISSION CONTROL UNIT CONNECTOR (Connected) Condition: • Ignition Switch: RUN		
Measure Between	Correct Voltage	For Diagnosis
11 (WT) & Ground	Greater than 10 Volts	See 1
21 (BK/BU) & Ground	Greater than 10 Volts	See 2
• If all the results are correct, go to the Symptom Table. 1. • Go to Test E: Motronic Control Unit Test, if the Fuel Rate Gauge does not operate. • Check/repair the WT wire, if the Fuel Rate Gauge operates. 2. • Go to Test E: Motronic Control Unit Test, if the Tachometer does not operate. • Check/repair the BK/BU wire if the Tachometer operates.		

D: HYDRAULIC PRESSURE REGULATOR AND SOLENOID TEST

Measure: RESISTANCE At: TRANSMISSION CONTROL UNIT CONNECTOR (Disconnected)		
Measure Between	Correct Resistance	For Diagnosis
1 (VI) & Ground	Greater than 500 K Ohms	See 1
1 (VI) & 25 (BU)	25 to 46 Ohms	See 2
1 (VI) & 20 (GY)	25 to 46 Ohms	See 2
1 (VI) & 17 (GN)	25 to 46 Ohms	See 2
1 (VI) & 16 (OR)	25 to 46 Ohms	See 2
1 (VI) & 22 (RD)	1.8 to 4.6 Ohms	See 3
• If all the results are correct, replace the Transmission Control Unit. 1. Check the wiring from terminals 1, 16, 17, 20, 22, and 25 for shorts to ground (see schematic). Check the Hydraulic Pressure Regulator and Solenoids for a short to ground if wiring is OK. Repair/replace as necessary. 2. Check/repair wire (see schematic) and connector terminal. Replace the Solenoid Valve (see schematic), if wire and connector terminal are OK. 3. Check/repair wire (see schematic) and connector terminal. Replace the Hydraulic Pressure Regulator Solenoid, if wire and connector terminal are OK.		

E: MOTRONIC CONTROL UNIT TEST

Measure: VOLTAGE At: MOTRONIC CONTROL UNIT CONNECTOR (Connected) Condition: • Ignition Switch: RUN		
Measure Between	Correct Voltage	For Diagnosis
10 (BR/GN) & Ground	Approximately 5 Volts	See 1
11 (WT) & Ground	Greater than 10 Volts	See 1
21 (BK/BU) & Ground	Greater than 10 Volts	See 1
3 (BR/BK) & Ground	Approximately 5 Volts	See 1
• If all the results are correct, check/repair the wire(s) to the Transmission Control Unit for an open(s). 1. Check the wire to the Transmission Control Unit for a short to ground (see schematic). Check/replace the Motronic Control Unit if wire is OK.		

F: PROGRAM SELECTOR SWITCH RETURN TEST

Measure: VOLTAGE At: PROGRAM SELECTOR SWITCH CONNECTOR C1 (Connected) Condition: <ul style="list-style-type: none"> • Ignition Switch: START 		
Measure Between	Correct Voltage	For Diagnosis
1 (BK) & Ground	Greater than 8 Volts	See 1
1 (BK) & 2 (BR)	Greater than 8 Volts	See 2
<ul style="list-style-type: none"> • If all the results are correct, replace the Program Selector Switch. <ol style="list-style-type: none"> 1. Check/repair the BK wire for an open (see schematic). 2. Check/repair the BR wire for an open (see schematic). 		

G: TRANSMISSION FAULT INDICATOR TEST (TABLE 1)

Measure: VOLTAGE At: TRANSMISSION CONTROL UNIT CONNECTOR (Connected) Condition: <ul style="list-style-type: none"> • Ignition Switch: RUN 		
Measure Between	Correct Voltage	For Diagnosis
33 (RD/WT) & Ground	Greater than 10 Volts	See 1
<ul style="list-style-type: none"> • If the voltage is correct, go to Table 2. <ol style="list-style-type: none"> 1. Replace the Transmission Control Unit. 		

G: TRANSMISSION FAULT INDICATOR TEST (TABLE 2)

Measure: VOLTAGE At: TRANSMISSION RANGE DISPLAY CONNECTOR (Disconnected) Condition: <ul style="list-style-type: none"> • Ignition Switch: RUN 		
Measure Between	Correct Voltage	For Diagnosis
1 (RD/WT) & Ground	Greater than 10 Volts	See 1
1 (RD/WT) & 2 (BR)	Greater than 10 Volts	See 2
<ul style="list-style-type: none"> • If all the voltages are correct, check the bulb and printed circuit board. Replace as necessary. <ol style="list-style-type: none"> 1. Check/repair the RD/WT wire for an open (see schematic). 2. Check/repair the BR wire for an open (see schematic). 		

H: 321 INDICATOR TEST

Measure: VOLTAGE At: TRANSMISSION RANGE DISPLAY CONNECTOR (Disconnected) Conditions: <ul style="list-style-type: none"> • Ignition Switch: RUN • Program Selector Switch: 321 		
Measure Between	Correct Voltage	For Diagnosis
3 (BR/WT) & Ground	0 Volts	See 1
12 (GN/BK) & Ground	Greater than 10 Volts	See 2
<ul style="list-style-type: none"> • If all the results are correct, check the GY wire bulb, printed circuit board, and connector terminals. Repair/replace as necessary. <ol style="list-style-type: none"> 1. Check/repair the BR/WT wire and the connector terminal (see schematic). 2. Check/repair the GN/BK wire for an open (see schematic). 		

I: PROGRAM SELECTOR SWITCH CONTINUITY TEST

Measure: RESISTANCE At: TRANSMISSION CONTROL UNIT CONNECTOR (Disconnected) Conditions: <ul style="list-style-type: none"> • Transmission Range Display Connector: Disconnected • Program Selector Switch: E 		
Measure Between	Correct Resistance	For Diagnosis
14 (BR/RD) & 6 (BR)	Approximately 0 Ohms	See 1
<ul style="list-style-type: none"> • Set Program Selector Switch to 321. 		
15 (BR/WT) & 6 (BR)	Approximately 0 Ohms	See 1
<ul style="list-style-type: none"> • Set Program Selector Switch to S. 		
14 (BR/RD) & 6 (BR)	Infinite Ohms	See 2
15 (BR/WT) & 6 (BR)	Infinite Ohms	See 2
<ul style="list-style-type: none"> • If all the results are correct, replace the Transmission Control Unit. <ol style="list-style-type: none"> 1. Check the wires and connector terminals (see schematic). Replace the Program Selector Switch if wires and connector terminals are OK. 2. Replace the Program Selector Switch. 		

J: TRANSMISSION SPEED SENSOR TEST (TABLE 1)

Measure: RESISTANCE At: TRANSMISSION CONTROL UNIT CONNECTOR (Disconnected)		
Measure Between	Correct Resistance	For Diagnosis
8 (BR/BK) & Ground	Greater than 500 K Ohms	See 1
8 (BR/BK) & 27 (WT)	800 Ohms to 1.6 K Ohms	See 2
<ul style="list-style-type: none"> • If all the results are correct, go to Table 2. <ol style="list-style-type: none"> 1. Check/repair the wires from terminals 8 and 27 for shorts to ground (see schematic). Replace the Transmission Speed Sensor if wires are OK. 2. Check/repair the wires from terminals 8 and 27 for opens (see schematic). Replace the Transmission Speed Sensor if wires are OK. 		

J: TRANSMISSION SPEED SENSOR TEST (TABLE 2)

Measure: AC VOLTAGE At: TRANSMISSION CONTROL UNIT CONNECTOR (Disconnected) Conditions: <ul style="list-style-type: none"> • Lift Car (rear wheels must turn freely) • Properly block suspension • Engine running • Gear Selector: D (Drive) • Speedometer: 30 km/h (20 mph) 		
Measure Between	Correct Voltage	For Diagnosis
8 (BR/BK) & 27 (WT)	Greater than 3.5 Volts AC	See 1
<ul style="list-style-type: none"> • If the result is correct, replace the Transmission Control Unit. <ol style="list-style-type: none"> 1. Replace the Transmission Output Speed Sensor. 		

K: KICKDOWN SWITCH TEST

Measure: VOLTAGE At: TRANSMISSION CONTROL UNIT CONNECTOR (Connected) Condition: <ul style="list-style-type: none"> • Ignition Switch: RUN 		
Measure Between	Correct Voltage	For Diagnosis
2 (GY/YL) & Ground	Approximately 5 Volts	See 1
<ul style="list-style-type: none"> • Depress accelerator pedal to Kickdown. 		
2 (GY/YL) & Ground	0 Volts	See 2
<ul style="list-style-type: none"> • If all the results are correct, check the BMW Troubleshooting Manual to verify the problem is not in the Transmission. Replace the Transmission Control Unit, if the problem is not in the Transmission. <ol style="list-style-type: none"> 1. Check the GY/YL wire and Kickdown Switch for a short to ground (see schematic). Replace the Transmission Control Unit if GY/YL wire and Kickdown Switch are OK. 2. Check the GY/YL wire for an open (see schematic). Replace the Kickdown Switch if GY/YL wire is OK. 		

L: GEAR INPUT TEST

Measure: VOLTAGE At: TRANSMISSION CONTROL UNIT CONNECTOR (Connected) Conditions: • Ignition Switch: RUN • Gear Selector: N (Neutral)		
Measure Between	Correct Voltage	For Diagnosis
4 (BU/BR) & Ground	Battery	See 1
• Put the Gear Selector in all positions except N (Neutral).		
4 (BU/BR) & Ground	Less than 1 Volt	See 2
• Put the Gear Selector in D (Drive).		
30 (BU/GN) & Ground	Battery	See 1
• Put the Gear Selector in all positions except D (Drive).		
30 (BU/GN) & Ground	Less than 1 Volt	See 2
• Put the Gear Selector in 3 (third gear).		
29 (BU/GY) & Ground	Battery	See 1
• Put the Gear Selector in all positions except 3 (third gear).		
29 (BU/GY) & Ground	Less than 1 Volt	See 2
• Put the Gear Selector in 2 (second gear).		
28 (BU/BK) & Ground	Battery	See 1
• Put the Gear Selector in all positions except 2 (second gear).		
28 (BU/BK) & Ground	Less than 1 Volt	See 2

• Put the Gear Selector in 1 (first gear).		
18 (BU/RD) & Ground	Battery	See 1
• Put the Gear Selector in all positions except 1 (first gear).		
18 (BU/RD) & Ground	Less than 1 Volt	See 2
• If all the results are correct, go to the Symptom Table.		
1. • If the associated bulb in the Transmission Range Display lights, check/repair the wire to the Automatic Transmission Range Switch for an open (see schematic).		
• If the associated bulb in the Transmission Range Display does not light, check/repair the Automatic Transmission Range Switch (see schematic).		
2. Check/repair the wire for a short to voltage and the Automatic Transmission Range Switch (see schematic).		

M: THROTTLE POSITION SENSOR AND WIDE OPEN THROTTLE OUTPUT TEST

Measure: VOLTAGE At: TRANSMISSION CONTROL UNIT CONNECTOR (Connected) Condition: • Ignition Switch: RUN		
Measure Between	Correct Voltage	For Diagnosis
31 (BR/BK) & Ground	Approximately 5 Volts	See 1
9 (BK) & Ground	Approximately 5 Volts	See 2

9 (BK) & 26 (BR)	Approximately 5 Volts	See 3
• Operate Throttle through its full range.		
7 (YL) & 26 (BR)	.7 Volts (Throttle closed) increasing evenly to 4.77 Volts (Throttle fully opened)	See 4
• Depress throttle pedal to the floor.		
31 (BR/BK) & Ground	Approximately .3 Volts	See 2
• If all the results are correct, go to the Symptom Table.		
1. Go to Test E: Motronic Control Unit Test.		
2. Replace the Transmission Control Unit.		
3. Check/repair BR wire to terminal 6 of the Transmission Control Unit for an open. Check the connector terminals.		
4. Check/repair the wiring to the Throttle Position Sensor. Adjust the Throttle Position Sensor if wiring is OK (see note). Replace the Throttle Position Sensor if adjustment does not correct the problem.		

NOTE: The highest voltage at full open position should be .22 volts less than the stabilized voltage. Adjust Throttle Position Sensor accordingly.


CIRCUIT OPERATION


By operating the Program Selector Switch, the driver can select 3 different transmission modes. When the Program Selector Switch is set to E (Economy), the Economy Input (terminal 14) in the Transmission Control Unit is grounded through terminal 6. The Economy Mode is designed for smooth, refined shift points and low fuel consumption. A fourth gear, or overdrive ratio, is available in the Economy Mode to reduce engine speed and noise level. When the Program Selector Switch is set to 321, the 321 Input (terminal 15), in the Transmission Control Unit, is grounded through terminal 6 and the 321 Indicator lights. The Transmission does not shift up or down and will operate in the selected gear only. When the Program Selector Switch is set to S, voltage is present at the Economy and 321 Inputs in the Transmission Control Unit. Fourth gear is not selected and first, second and third gears are kept selected up to full engine speed. The Program Selector Switch is designed to return to E when the engine is cranked. When the engine is cranked, voltage is applied to the coil in the Program Selector Switch through the Ignition Switch and the Start Relay. The coil energizes and the Program Selector Switch returns to E.

The Transmission Control Unit monitors engine speed (terminal 21), fuel rate (terminal 11), Throttle position (terminal 7), road speed (terminals 8 and 27), Kickdown signal (terminal 2), Gear Selector position (terminals 4, 30, 29, 28 and 18) and Program Selector Switch position (terminals 14 and 15). The Transmission Control Unit's electronic processing circuit compares this information with the program data to establish the correct gear and smooth shift points, by controlling the Shift Valve Solenoids and the Hydraulic Pressure Regulator.



The Transmission Fault Indicator will light with the engine running, if a problem with the control system occurs. When a fault is detected, the vehicle can only be driven in third and reverse gears. Neutral and Park also retain their functions. Voltage to the transmission (terminal 1) is not present when a fault is detected.

The Reverse Gear Inhibit Lock Solenoid prevents the driver from selecting reverse above 5 mph.







HOT IN RUN OR START




1. MOTOR DIRECTION CONTROLLED BY POLARITY
2. WITH CLUTCH SOLENOID ENERGIZED MOTOR TURNS MIRROR LEFT OR RIGHT
3. ELECTRICALLY HEATED MIRROR TURNS ON BELOW $59 \pm 9^\circ \text{ F}$ AND TURNS OFF ABOVE $122 \pm 18^\circ \text{ F}$



MIRROR CONTROL SWITCH





TROUBLESHOOTING HINT

Check Fuse 5 by operating the Digital Radio.

SYSTEM CHECK

- Operate controls in sequence listed in the System Check Table.
- Refer to Repair Action for the Response received (Tests follow the System Check Table).
- After any repair, repeat System Check to verify proper system operation.

NOTE: Before replacing any system component, check all connectors, splices, and wiring to that component.

COMPONENT LOCATION

		Page-Figure
Central Locking Control Unit	Behind RH kick panel, above speaker	7000-10-3
Door Lock Motors	Center rear of respective door	7000-10-4
Gas Filler Lock Motor	In trunk, right of power antenna	7000-12-4
Ignition Switch	Upper part of steering column	
Power Distribution Box	On LH front wheel well	7000- 3-2
Right Front Door Micro Switch	Inside RH front door, mounted on door lock	7000-10-4
Trunk Lock Motor	In rear panel of trunk	7000-12-3
Unlock Inhibit Switch	In LH front door, on door lock	7000- 9-4
C200 (10 pin)	On LH side of steering column	7000- 7-6
C206 (29 pin)	On connector bracket, under LH side of dash	7000- 7-4
C302 (Accessory Connector)	Under LH side of dash	7000- 7-4
C400 (13 pin)	Behind LH front speaker	7000- 9-2
C401 (13 pin)	Behind RH front speaker	7000-10-3
C402 (7 pin)	In LH B pillar	
C403 (7 pin)	In RH B pillar	7000-5-6
C404 (5 pin)	In bottom rear of LH front door	
C405 (2 pin)	In trunk, near trunk lock	
G200 (Front Interior Ground)	Under LH side of dash, near brake bracket	7000- 7-6

SYSTEM CHECK TABLE

OPERATION	RESPONSE	REPAIR ACTION
1. Insert the key in the Driver's door and turn to LOCK	All doors lock	None, proceed to Operation 2
	Some doors lock	Repair/replace the suspect Door Lock Motor circuit
	No doors lock	Proceed to Operation 4
2. Turn the key to UNLOCK INHIBIT (clockwise until key is horizontal)	All doors double lock (Safety Catch Buttons cannot be pulled up by hand)	None, proceed to Operation 3
	Driver's door double locks and only some of the other doors double lock	Repair/replace the suspect Door Lock Motor
	Driver's door double locks but all the other doors do not double lock	Turn key to UNLOCK. If any door unlocks, check RD/BR wire and Unlock Inhibit Switch. If no doors unlock, proceed to Test B.
	Driver's door does not double lock	Mechanical problem, see BMW Troubleshooting Manual

SYSTEM CHECK TABLE (CONT'D)

OPERATION	RESPONSE	REPAIR ACTION
3. Turn the key to UNLOCK	All doors unlock	None, proceed to Operation 4
	Some doors unlock	Repair/replace the suspect Door Lock Motor circuit
	No doors unlock	Proceed to Operation 5
4. Insert the key in the Passenger's door and turn to LOCK	All doors lock	If the doors did not lock in Operation 1, repair/replace the Driver's Door Lock Switch, otherwise proceed to Operation 5
	Some doors lock	Repair/replace the suspect Door Lock Motor circuit
	No doors lock	If all the doors locked in Operation 1, repair/replace the Right Front Door Microswitch. If the doors did not lock in Operation 1, perform Test A
5. Insert the key in the Passenger's door and turn to UNLOCK	All doors unlock	If all the doors did not unlock in Operation 3, repair/replace the Driver's Door Lock Switch, otherwise proceed to Operation 6
	Some doors unlock	Repair/replace the suspect Door Lock Motor
	No doors unlock	If all the doors unlocked in Operation 3, repair/replace the Passenger's Door Lock Switch. If the doors did not unlock in Operation 3, perform Test C
6. Get in the car and close and lock all doors Turn the Ignition Switch to RUN	Doors remain locked	None, proceed to Operation 7
	Doors unlock	Repair/replace the Central Locking Control Unit
7. Get out of the car Insert the key in the Driver's door and turn to LOCK Unlock each of the doors by pulling up the Safety Catch Buttons	All doors can be unlocked	None, proceed to Operation 8
	All doors remain secure	Disconnect the connector from the Central Locking Control Unit and check for a short to battery in the RD/BR, WT/BU, and BK/WT wires at terminal 10. <ul style="list-style-type: none"> • If short to battery is not present, replace the Unlock Inhibit Switch. • If short to battery is present, isolate wiring from Door Lock Motors one at a time to find short

SYSTEM CHECK TABLE (CONT'D)

OPERATION	RESPONSE	REPAIR ACTION
8. Insert the key in the Trunk Cylinder Switch. Turn the key to LOCK	Trunk locks	None, proceed to Operation 9
	Trunk does not lock	If the doors lock, repair/replace the Trunk Lock Motor Circuit or Trunk Lock Motor. If the doors do not lock, repair/replace the Trunk Switch. Repair/replace the Central Locking Control Unit if the Trunk Switch Circuit is OK
9. Turn the key to UNLOCK	Trunk unlocks	None, proceed to Operation 10
	Trunk does not unlock	If the doors unlock, repair/replace the Trunk Lock Motor circuit or Trunk Lock Motor. If the doors do not unlock, repair/replace the Trunk Switch. Repair/replace the Central Locking Control Unit if the Trunk Switch Circuit is OK
10. Turn the key back to LOCK	Gas Filler locks	None, proceed to Operation 11
	Gas Filler does not lock	Repair/replace the Gas Filler Lock Motor circuit
11. Turn the key to UNLOCK	Gas Filler unlocks	None
	Gas Filler does not unlock	Repair/replace the Gas Filler Lock Motor circuit

- If all results are normal, the system is OK.

SYSTEM DIAGNOSIS

- Do the following tests when directed by the System Check Table.

A: CONTROL UNIT LOCK TEST (TABLE 1)

Measure: VOLTAGE At: CONTROL UNIT CONNECTOR (Connected)		
Measure Between	Correct Voltage	For Diagnosis
3 (RD/WT) & Ground	Battery	See 1
3 (RD/WT) & 4 (BR)	Battery	See 2
<ul style="list-style-type: none"> • If the voltages are correct, proceed to Table 2. <ol style="list-style-type: none"> 1. Check the RD/WT wire for an open. 2. Check the BR wire for an open to ground (see schematic). 		

A: CONTROL UNIT LOCK TEST (TABLE 2)

Connect: A FUSED JUMPER At: CONTROL UNIT CONNECTOR (Connected)		
Jumper Between	Correct Result	For Diagnosis
7 (YL/BU) & Ground	Doors lock	See 1
<ul style="list-style-type: none"> • If the result is correct, repair/replace the switches and related wiring (see schematic). <ol style="list-style-type: none"> 1. Proceed to Table 3. 		

A: CONTROL UNIT LOCK TEST (TABLE 3)

Connect: FUSED JUMPER At: CONTROL UNIT CONNECTOR (Disconnected)		
Jumper Between	Correct Result	For Diagnosis
1 (BU) & 3 (RD/WT) 2 (WT) & 4 (BR)	Doors lock	See 1
<ul style="list-style-type: none"> If the result is correct, replace the Central Locking Control Unit. <ol style="list-style-type: none"> Check the BU wire to splice S405 and the WT wire to splice S406 for opens (see schematic). 		

B: UNLOCK INHIBIT TEST (TABLE 1)

Measure: RESISTANCE At: CONTROL UNIT CONNECTOR (Disconnected)		
Conditions		
<ul style="list-style-type: none"> Driver's Door Lock: UNLOCK INHIBIT 		
Measure Between	Correct Resistance	For Diagnosis
10 (RD/BR) & Ground	1 K ohm	See 1
<ul style="list-style-type: none"> If the resistance is correct but the unlock inhibit only operates on the Driver's Lock, replace the Central Locking Central Unit. <ol style="list-style-type: none"> Check for opens in the WT/BK, BK/WT and BR wires. If OK, proceed to Table 2. 		

B: UNLOCK INHIBIT TEST (TABLE 2)

Measure: RESISTANCE At: LH FRONT DOOR LOCK MOTOR (Disconnected)		
Measure Between	Correct Result	For Diagnosis
Terminal 6 and Terminal 5	1 K ohm	See 1
<ul style="list-style-type: none"> If resistance is correct, replace the Unlock Inhibit Switch. <ol style="list-style-type: none"> Replace RH Front Door Lock Motor. 		

C: CONTROL UNIT UNLOCK TEST

Connect: A FUSED JUMPER At: CONTROL UNIT CONNECTOR (Connected)		
Jumper Between	Correct Result	For Diagnosis
6 (GN/BU) & Ground	Doors unlock	See 1
<ul style="list-style-type: none"> If the result is correct, repair/replace the switches and related wiring (see schematic). <ol style="list-style-type: none"> Replace the Central Locking Control Unit. 		

CIRCUIT DESCRIPTION

The Central Locking System is controlled by the Central Locking Control Unit. This unit senses when a lock switch is moved by a key, and sends the appropriate signal to drive the Motors. The Central Lock Control Unit controls the Door Locks, Gas Filler Lock and Trunk Lock. The unit also has an Inertia Switch which closes on impact greater than 5g. If in RUN or START the locks are then unlocked.

Lock

When the Key is inserted into a lock and turned clockwise, the Lock switch moves to LOCK and grounds terminal 7 of the Central Locking Control Unit. The unit activates the Lock Relay and applies voltage from Fuse 5 to the Lock Motor, which is grounded through the WT wire, Central Locking Control Unit and BR wire. The Lock Motor then pulls the lock down. As the motor runs, a switch is gradually moved from terminal 2 to terminal 6 of all but the Driver's Lock Motor. At terminal 6, the switch position prevents voltage from being applied to the motor. The door locks also control the Trunk Lock and Gas Filler Lock.

Unlock

When the key is turned counterclockwise, terminal G of the Central Locking Control Unit is grounded through the Lock Switch. The Central Locking Control Unit then activates the Unlock Relay and applies voltage from Fuse 5, through the WT wire to the Lock Motor. The motor is grounded through the BU wire, Central Locking Control Unit, and BR wire. The polarity is reversed and the motor pushes the lock up. As the motor runs, the switch is returned to terminal 2.

Unlock Inhibit

When the key is inserted into the Driver's Lock and turned clockwise past the LOCK position, the Unlock inhibit mechanism is engaged. This mechanically inserts a bar into the driver's lock and prevents unlocking through use of the Safety Catch Button. When in the Unlock Inhibit position, the Central Locking Unit is grounded at terminal 10. The unit then activates the Lock Relay, and voltage is applied to the motors through the Unlock Inhibit Switch and BK/WT wires. The motors are again acti-


vated and engage their Unlock Inhibit mechanisms.


Trunk Lock

The Trunk Lock operates in a manner similar to the Door Locks.


EARLY PRODUCTION

HOT IN RUN OR START HOT AT ALL TIMES








LATE PRODUCTION




LATE PRODUCTION








EARLY PRODUCTION




LATE PRODUCTION




HORN


HOT IN ACCY. RUN OR START





REAR DEFOGGER




HEATED DOOR LOCKS




CIGAR LIGHTER/GLOVE BOX LIGHT/AUTO-CHARGING FLASHLIGHT







WIPER/WASHER AND HEATED WASHER JETS



SPEEDOMETER/GAUGES/WARNING INDICATORS EARLY PRODUCTION




GAUGES/WARNING INDICATORS EARLY PRODUCTION




Rear Of Instrument Cluster


INSTRUMENT CLUSTER PRINTED CIRCUIT




WARNING INDICATORS EARLY PRODUCTION




SERVICE INTERVAL INDICATOR EARLY PRODUCTION




SPEEDOMETER/GAUGES/WARNING INDICATORS LATE PRODUCTION




GAUGES/WARNING INDICATORS LATE PRODUCTION




INSTRUMENT CLUSTER
PRINTED CIRCUIT



WARNING INDICATORS LATE PRODUCTION



SERVICE INTERVAL INDICATOR LATE PRODUCTION









Figure 1 - Above Rear View Mirror


ACTIVE CHECK CONTROL


1. When the Ignition Switch is initially placed in "Run," the Active Check Control Alarm Indicator flashes, and the Active Check Control Unit Brake Light LED and panel light illuminate for test purposes. Depressing the brake pedal clears the display.
2. When the Ignition Switch is placed in "Run," fault monitoring begins. To monitor the low beams, rear lights, or license lights, those circuits must be on. The brake lights are monitored only while the brake pedal is depressed.
3. When a fault occurs, the alarm indicator flashes, the appropriate LED indicator lights, and the panel light goes on for five seconds. Depressing the test button will clear the alarm indicator, but the LED fault indicator remains on.
4. To test the unit, depress the test button. The LED fault indicators and panel light should go on.













LIGHTS: DASH/TRANSMISSION RANGE




LIGHTS: DASH/TRANSMISSION RANGE


HOT IN RUN ONLY FROM UNLOADER RELAY





CONTROL





CONTINUED ON PAGE 6312-1






















HEATER AND A/C TEMPERATURE CONTROL





HEATER AND A/C BLOWER CONTROLS


HOT IN RUN ONLY FROM UNLOADER RELAY





A/C FRESH AIR DOOR CONTROL
















EARLY PRODUCTION



LATE PRODUCTION



INDEX

This index contains all the splices in the car, what harness each one is in, and the page that the splices appear on. The drawings after the index show how the harness is routed through the car and where the splices are located on the harness.


SPLICE	HARNESS	PAGE NUMBER	SPLICE	HARNESS	PAGE NUMBER
S100	FRONT	8000-5	S219	MIDDLE	8000-6
S101	FRONT	8000-5	S220	MIDDLE	8000-6
S102	FRONT	8000-5	S221	MIDDLE	8000-6
S103	FRONT	8000-5	S222	CRUISE CONTROL	8000-2
S104	FRONT	8000-5	S223	CRUISE CONTROL	8000-2
S105	ENGINE	8000-1	S224	CRUISE CONTROL	8000-2
S106	ENGINE	8000-1	S225	A/C	NOT SHOWN
S109	ENGINE	8000-1	S226	A/C	NOT SHOWN
S110	ENGINE	8000-1	S227	A/C	NOT SHOWN
S112	ENGINE	8000-1	S228	A/C	8000-2
S114	HEATER	NOT SHOWN	S229	A/C	8000-2
S119	HEATED WASHER JETS	NOT SHOWN	S231	MIDDLE	8000-6
S120	FRONT	8000-5	S232	POWER SEATS	NOT SHOWN
S121	ELECT TRANS	NOT SHOWN	S233	POWER SEATS	NOT SHOWN
S200	MIDDLE	8000-6	S234	MIDDLE	NOT SHOWN
S201	MIDDLE	8000-6	S235	REAR	8000-4
S202	MIDDLE	8000-6	S300	REAR	8000-4
S203	MIDDLE	8000-6	S303	REAR	8000-4
S204	MIDDLE	8000-6	S304	REAR	8000-4
S205	MIDDLE	8000-6	S305	REAR	8000-4
S206	MIDDLE	8000-6	S306	REAR	8000-4
S207	MIDDLE	8000-6	S308	REAR	8000-4
S208	MIDDLE	8000-6	S309	REAR	8000-4
S209	MIDDLE	8000-6	S310	REAR	8000-4
S210	MIDDLE	8000-6	S311	REAR	8000-4
S211	MIDDLE	8000-6	S312	REAR	8000-4
S212	MIDDLE	8000-6			
S213	MIDDLE	8000-6			
S214	MIDDLE	8000-6			
S215	MIDDLE	8000-6			
S216	MIDDLE	8000-6			
S217	MIDDLE	8000-6			
S218	MIDDLE	8000-6			

INDEX


This index contains all the splices in the car, what harness each one is in, and the page that the splices appear on. The drawings after the index show how the harness is routed through the car and where the splices are located on the harness.

SPLICE	HARNESS	PAGE NUMBER	SPLICE	HARNESS	PAGE NUMBER
S313	REAR	8000-4	S416	CENTRAL LOCKING	8000-7
S314	REAR	8000-4	S417	CENTRAL LOCKING	8000-7
S315	REAR	8000-4	S418	PASSENGER DOOR	8000-3
S316	REAR	8000-4	S420	RADIO	NOT SHOWN
S317	REAR	8000-4	S500	DRIVER'S DOOR	8000-3
S318	REAR	8000-4	S501	DRIVER'S DOOR	8000-3
S319	REAR	8000-4	S502	DRIVER'S DOOR	8000-3
S320	REAR	8000-4	S503	DRIVER'S DOOR	8000-3
S400	CENTRAL LOCKING	8000-7	S504	DRIVER'S DOOR	8000-3
S401	CENTRAL LOCKING	8000-7	S600	SUNROOF	NOT SHOWN
S402	CENTRAL LOCKING	8000-7	S601	SUNROOF	NOT SHOWN
S403	CENTRAL LOCKING	8000-7	S700	ABS	NOT SHOWN
S404	CENTRAL LOCKING	8000-7	S701	ABS	NOT SHOWN
S405	CENTRAL LOCKING	8000-7			
S406	CENTRAL LOCKING	8000-7			
S407	CENTRAL LOCKING	8000-7			
S408	CENTRAL LOCKING	8000-7			
S409	CENTRAL LOCKING	NOT SHOWN			
S410	CENTRAL LOCKING	8000-7			
S411	CENTRAL LOCKING	8000-7			
S412	CENTRAL LOCKING	8000-7			
S414	CENTRAL LOCKING	8000-7			
	CENTRAL LOCKING	8000-7			


ENGINE HARNESS SPLICE LOCATIONS




A/C AND CRUISE HARNESS SPLICE LOCATIONS




DOOR HARNESS SPLICE LOCATIONS




REAR HARNESS SPlice LOCATIONS




FRONT HARNESS SPLICE LOCATIONS



A/C AND CRUISE HARNESS



CENTRAL LOCKING HARNESS SPLICE LOCATIONS



**FOR COMPONENT LOCATION VIEWS,
CONNECTOR VIEWS AND COMPONENT
LOCATION CHART, SEE SECTION A. (528e)**